


Let's build the

Novi Dresser

SKU 71250



Scan me!

Free Lifetime
Guarantee

 **nathan james**

25-1202-VN

Ok, let's get rolling

This should be easy, just follow our instructions and you will be back to Netflix in no time.

Estimated time for assembly




30:00

What you need

- Some of your favourite bubbly or your preferred relaxant
- Use the packaging carton as a working surface to prevent product damage during assembly
- Phillips-head screwdriver
- Drill bit 1/4" or 5/16"

Weight Limitation



Top Max. Capacity: 40 lbs

Top Drawer Max. Capacity : 10lbs

Middle Drawer Max. Capacity : 10lbs

Bottom Drawer Max. Capacity : 10lbs

Toll-free at 1-866-619-1004

Help@nathanjames.com

Nathanjames.com/help

What's included



	Description	Qty
A	Cabinet Assembly	1
B	Side Leg Frame	2
C	Stretcher	1
1	Ø1/4" x 38mm Hex Button Head Bolt	6
2	Ø1/4" x 10mm Spring Washer	6
3	Ø1/4" x 13mm Flat Washer	6
4	Allen Key	1
5	Cam Bolt	2
6	Cam Lock	2
7	Ø8x20mm Wooden Dowel	6
8	Leveler (Extra)	2
9	Plastic Bracket (for Anti-Tip Kit)	2
10	Non-Drywall Anchor (for Anti-Tip Kit)	2
11	M3.5 x15mm Screw (for Anti-Tip Kit)	2
12	Plastic Tether Strap (for Anti-Tip Kit)	1
13	M4 x 50mm Screw (for Anti-Tip Kit)	2
14	Drywall Anchor (for Anti-Tip Kit)	2

Scan me!

Free Lifetime
Guarantee



The goods



IMPORTANT

1. Do not tighten bolts / screws completely until all bolts / screws are lined up and inserted into holes.
2. Do not over tighten screws and bolts to avoid stripping.
3. Please use hand tools to assemble this product.


How to use cam locks

Did you know?

Cam locks are used to join two panels together, usually the edge of one to the flat side of another.


First, your cam bolt (or cam pin) will need to be properly inserted into the flat side of the board.

Important Note: Only tighten the cam bolt until it is secure. Do not over-tighten.




Next, you will fit the proper hole on the edge of the associated joining panel over the cam bolt.

Important Note: When installed properly, the head of the cam bolt will be visible through the larger hole on the side of the joining panel.




Next, you will notice the cam lock has a “C” shaped back. Commonly, an arrow on the front of the cam lock points in the same direction as the open section on back.

Using these as your cue, insert the cam lock into the large hole so the opening of the “C” fits over the head of the cam bolt.



Using a screwdriver, you will turn the cam lock until it stops, usually at 90° or 180°. You will feel the panels pulling closer until they are secured.

Important Note: Only turn the cam lock until the panels are fully engaged & feel secure. Turning too far may lead to hardware failure.



Still having issues?

If a cam lock seems to be spinning in place or is not “catching” or pulling the panels together as expected, first remove the cam lock & try again while making sure that everything is properly positioned & oriented.

If you are still having issues getting things working as expected, first remove the cam lock, then unscrew the cam bolt slightly (less than 1 complete turn) to see if that helps with the alignment of the cam lock & bolt.


Step 1

Lay down the packaging or use your carpet as a protective work surface and let's get started!
Screw the Cam Bolts (5) into the Side Leg Frame (B).

5





x2pcs



Step 2

Insert one Wooden Dowel (7) into each end of the Stretcher (C).
Then place the Side Leg Frame (B) over the Wooden Dowels (7).
Make sure to line things up as shown below.
Finally, use the Cam Lock (6) to secure the Side Leg Frames (B) to the Stretcher (C).





Step 3

First, insert four Wooden Dowels (7) into the Cabinet Assembly (A). Then place the base that you assembled in Step 2 over the Wooden Dowels (7).

Make sure to line things up as shown below.

Next, slide the Spring Washers (2) and Flat Washers (3) onto the Bolts (1). Use these parts and the Allen Key (4) to secure the base from Step 2 to the bottom of the Cabinet Assembly (A).




Step 4

Carefully flip the Dresser over.




Only one drawer can be opened at a time, If you open
Example: If you open the top drawer, the bottom drawer
and the middle drawer must be completely closed.




Step 5

Now go ahead and check that your Novi Dresser is level and not wobbly. If it's looking a little uneven, adjust the levelers on the feet until it's nice and level.




Wobbly or unlevel
Adjust the feet until stable


How to Use Drywall Anchors




1. Drill hole 5/16 bit.



2. Pinch and insert.



3. Begin tightening.





4. Anchor is secure when screw is tightened to 100%.

Step 6

Safety first! Let's get this dresser secured to the wall. Find where you want your dresser to live before you begin installing the wall anchors.

First, determine which style of wall anchor you will need, then using the proper, recommended drill bit & the Plastic Bracket (9) as your hole guide, you will drill 2 holes in your wall before finally inserting the anchors into the wall.

You will need either a 1/4" drill bit or a 5/16" drill bit for this step, depending on your wall type.





IMPORTANT NOTE:

Non-Drywall Anchor (10) requires 1/4" Drill Bit
Drywall Anchor (14) requires 5/16" Drill Bit

Step 14

Next, you will secure the other Plastic Bracket (9) to the back of the dresser using the M3.5 x 15mm Screws (11) before looping the Plastic Tether Strap (12) through both Plastic Brackets & pulling it through itself to secure the cabinet.



IMPORTANT NOTE:

Young children (and/or pets) can be seriously injured by tipping furniture units.

You must install the provided anti-tip kit hardware solution, as instructed, to prevent the furniture unit(s) from tipping over - which could possibly lead to injuries or damage.

The provided anti-tip kit hardware solution is intended only as an additional safety measure & deterrent; it is not a substitute for proper adult supervision.

The provided anti-tip kit hardware solution is not an earthquake restraint. If you wish to add the extra security of earthquake restraints, they must be purchased & installed separately.

No heartburn, when we handle the return

Give us a call **1-866-619-1004** or shoot us a message at **help@nathanjames.com** we will issue you a free replacement with **zero hassle**.

Our way



Give us a call



Replacement



You

Their way



Re-package item



Schedule pick up



Track package



Replacement



You

We really don't want you to go through the hassle of re-packaging your item and sending it back, because let's be honest...nobody has time for that.

Safety first, fun later

We want your product to last as long as possible, so we recommend that you tighten the screws 2 weeks after assembly and for added safety check the tightness of all screws every 2 months.

For proper care and treatment, please check our website at NathanJames.com/products

Safe use of this product starts with you.

Use this product responsibly with the primary concern for your safety. Follow assembly instructions carefully and inspect product upon receipt and each use.

Nathan James and its parent companies cannot be held legally responsible for any injuries or death resulting from failure to follow instructions or improper use of this product.

Do not modify the structure of this product in any way.

Our products have been tested to meet specific safety measures as they were originally intended to be sold. Any modifications will present the risk of creating significant safety issues which NJ will not be responsible for.

Proper use

- DO NOT** use for commercial purposes
- DO NOT** climb on dresser
- DO NOT** exceed weight limit
- DO NOT** leave spilled liquid on dresser
- DO NOT** use if dresser is damaged or broken
- DO NOT** make temporary repairs
- DO NOT** use outdoors

We are only in business if you're happy

For starters, thanks for being you.

☎ Toll-free at 1-866-619-1004

✉ Help@nathanjames.com

🌐 NathanJames.com/help

We do our best to ensure your furniture arrives without any problems, but occasionally mistakes happen—as humans we are imperfect beings. In the event that a part is damaged or missing, we will be more than happy to provide you with replacement part(s) for free.

Lifetime Guarantee

We believe in making things that last. That's why every product is backed by our Lifetime Guarantee. No hidden clauses. No runaround. If it breaks, we'll replace it—plain and simple. This isn't just a promise—it's our commitment to quality, and to you.

This product comes with a Lifetime Guarantee from the date of purchase. Please use your phone to scan the QR code on the cover of this booklet to register your product or visit <https://goo.gl/i9dk3q>



Did we do alright? Please spread the love!

If you are happy with your product, tell your friends and family about us, or even better, leave us a review online. Spreading the word gives us the opportunity to make more people happy and keep our prices low for your next purchase.

Brooke Burdon

Founder, Nathan James