


Assembly Instructions

Caution: You must read this before you proceed

Care & Maintenance

	<ul style="list-style-type: none">• Not for commercial use. For residential use only.
	<ul style="list-style-type: none">• Do not put hot items directly on furniture surface.
	<ul style="list-style-type: none">• Do not clean furniture with harsh cleansers or polish.
	<ul style="list-style-type: none">• Do not place furniture under direct sunlight.
	<ul style="list-style-type: none">• Do not place furniture near heating or cooling vents.
	<ul style="list-style-type: none">• Do not write on furniture without a padded barrier to protect the surface.
	<ul style="list-style-type: none">• Do not place furniture outside . For indoor use only.
	<ul style="list-style-type: none">• Stains may be removed with mild soap solution and damp cloth.
	<ul style="list-style-type: none">• Children should not climb or jump on the furniture.
	<ul style="list-style-type: none">• Dust and pick-up spills using a clean, non-colored, lint-free cloth.


Please look in Corners of carton for hardware packs and Legs.

Assembly Instructions

Please look in the Box for Hardware packs and Legs

DINING CHAIR

Item No: N776P385750








Caution: This Dining Chair is NOT a TOY. Keep your child / children at bay during the assembly process. Whenever lifting or moving the Chair and to prevent damage to the chair, two adults may be needed to execute these actions.

ASSEMBLY INSTRUCTION

ITEM NO. N776P385750


Parts List

Label	Picture	Description	QTY
A	 A line drawing of a chair's left side arm, showing a mesh backrest and a curved top rail.	Left Side Arm	1
B	 A line drawing of a chair's right side arm, showing a mesh backrest and a curved top rail.	Right Side Arm	1
C	 A line drawing of a square chair seat with a mesh top and a wooden frame.	Chair Seat	1
D	 A line drawing of a chair backrest, showing a mesh panel and a wooden frame.	Chair Back	1
E	 A line drawing of two long, thin wooden cross bars with notches at the ends.	Cross Bar	2

ASSEMBLY INSTRUCTION


ITEM NO. N776P385750

Hardware

Label	Picture	Description	QTY
①		Bolt (1/4" x 38mm)	7
②		Bolt (1/4" x 45mm)	5
③		Bolt (1/4" x 60mm)	3
④		Bolt (1/4" x 80mm)	3
⑤		Spring Washer (φ6 x 12)	13
⑥		Flat Washer (φ6 x 12)	13
⑦		Allen Wrench (K4 x 80)	1
⑧		Haft moon Nut	5
⑨		Wooden Dowel (10 x 30)	3
⑩		T nut	3

Assembly Preparation


Before Beginning Assembly:



-  • Read instructions, cover to cover-
-  • Have 2 adults on hand for assembly-
-  • Do not assemble on flooring or carpet-
-  • Assemble on a clean non-marring surface (packing foam)-
-  • Save all packaging until finished-

Assembly Steps

Overview




This Dining Chair has multiple parts and may require up to 30 minutes to assemble. To give you an overview of the Dining Chair parts, the above picture is to help you put the various parts into perspective. Please read through the instructions below to familiarise yourself with the parts and steps before assembly.

ASSEMBLY INSTRUCTION

ITEM NO. N776P385750


Step 1



Place all the parts on a clean, non-marring surface.

REMOVE the Seat Base Cover from the Chaire Seat(C),

Step 2





Secure the Chair Seat (C) to the Left side Arm (A). Using the Bolt (①) + Spring Washer (⑤) + Flat Washer (⑥) With the Allen Wrench (⑦).

Do Not fully tighten the connections.

ASSEMBLY INSTRUCTION

ITEM NO. N776P385750

Step 3




Next, assembly the Cross Bar (E) to the Left side Arm (A). Using the Bolt (②) + Haft moon Nut (⑧) With the Allen Wrench (⑦).
Do Not fully tighten the connections.

ASSEMBLY INSTRUCTION

ITEM NO. N776P385750

Step 4




Next, assembly the Right Side Arm (B) To the Chair Seat (C) and Cross Bar (E). Using the Bolt (①) + Spring Washer (⑤) + Flat Washer (⑥) With the Allen Wrench (⑦). Then assembly the Cross Bar (E) to the Right Side Arm (B). Using the Bolt (②) + Haft moon Nut (⑧) + With the Allen Wrench (⑦). Do Not fully tighten the connections. Close the Seat Base Cover from the Chair Seat © after the all Bolt make sure tightening 100%.

ASSEMBLY INSTRUCTION

ITEM NO. N776P385750

Step 5




Next, assembly the Chair Back (D) To the Left Side Arm (A) and Right Side Arm (B). Align by Woodendowel (9). Then Using the Bolt (3) + Spring Washer (5) + Flat Washer (6) to connect Chair Back (D) with Leg of Side.

Using the Bolt (4) + Spring Washer (5) + Flat Washer (6) to connect Chair Back (D) with Arm of side .Please insert the T Nut (10) before assembly.

Fully tighten the connections.

ASSEMBLY INSTRUCTION
ITEM NO. **N776P385750**

Step 6



Last but not least, flip the Chair over on a flat surface & make sure all Part are touching before tightening everything from to 100%.

Stand the chair right side up. Your Chair is ready for use.

This Dining Chair can only be used on a flat, level surface.