

Assembly Instructions


CAUTION: You must read these Assembly Instructions before you proceed.

Care & Maintenance

- ⊘  • Not for commercial use. For residential use only.
- ⊘  • Do not put hot items directly on furniture surface.
- ⊘  • Do not clean furniture with harsh cleansers or polish.
- ✓  • To obtain the longest lifespan of your outdoor products, minimizing exposure to direct sunlight is recommended.
- ⊘  • Children should not climb or jump on the furniture.
- ⊘  • Do not write on furniture without a padded barrier to protect the surface.
- ✓  • To obtain the longest lifespan of your outdoor products, avoid extended and lengthy exposure to rain, snow, and direct sunshine. Whenever possible cover the product and /or place under patio or awnings.
- ⊘  • Stains may be removed with mild soap solution and damp cloth.
- ✓  • Keep away from sources of ignition.
- ✓  • Dust and pick-up spills using a clean, non-colored, lint- free cloth.







Please look in Seat Panel for hardware packs

DINING CHAIR





CAUTION: This Dining Chair is NOT a TOY.
Keep your child / children at bay in the process of assembly.
For turning the Dining chair and to prevent damage to the Dining Chair,
two adults persons may be needed to execute this action

Parts List:


Label	Picture	Description	Qty
A	 <p>A technical drawing of a backrest panel. It consists of a rectangular frame with a central vertical support. The top and bottom horizontal rails have four circular holes each. A mesh-like material is attached to the top and bottom rails, extending upwards and downwards from the central support.</p>	Backrest Panel	1
B	 <p>A technical drawing of a seat panel. It is a rectangular, woven mesh structure with a diamond-shaped pattern. The mesh is supported by a frame of thicker material around the perimeter.</p>	Seat Panel	1
C	 <p>A technical drawing of a long, cylindrical leg. It has four circular holes along its length. At one end, there are two small circular features, possibly for attachment.</p>	Left Leg	1
D	 <p>A technical drawing of a long, cylindrical leg, identical to the left leg. It has four circular holes along its length and two small circular features at one end.</p>	Right Leg	1
E	 <p>A technical drawing of a long, cylindrical support bar. It has two circular holes at one end and a small circular feature at the other end.</p>	Front Support Bar	1
F	 <p>A technical drawing of a long, cylindrical support bar, identical to the front support bar. It has two circular holes at one end and a small circular feature at the other end.</p>	Side Support Bar	2

Hardware:

Label	Picture	Description	Qty
①		AllenWrench	1
②		Screw (M6x80mm)	3
③		Screw (M6x60mm)	7
④		Bolt (M6x65mm)	9
⑤		Washer (Ø7xØ16x2mm)	9

Assembly Preparation:

Before Beginning Assembly:



- Read instructions, cover to cover-



- Have 2 adults on hand for assembly-



- Do not assemble on flooring or carpet-




- Assemble on a clean non-marring surface (packing foam)-



- Save all packaging until finished-


Assembly Steps:

OVERVIEW




This Dining Chair has multiple parts and may require up to some 30 minutes to assemble. To give you an overview of the Dining Chair, the above picture is to help you put the various parts into perspective. Please read through the instructions here below to familiarise yourself with the parts and steps before assembly.

Step 1



Unpack and place all parts on a clean, non-marring surface.


Step 2



With assistance from your adult partner, place Seat Panel (B) facing down then attach Left Leg (C) to Seat Panel (B) by using Bolts (④) and Washers (⑤) with Allen Wrench (①) as shown above.


Do not fully tighten the Bolts.

Step 3



With assistance from your adult partner, attach Front Support Bar (E) to Left Leg (C) of the assembled part in Step 2 by using Screw (③) with Allen Wrench (①).

Do not fully tighten the Screw.




With assistance from your adult partner, attach Right Leg (D) to the assembled part in Step 3 as shown above. Then:

Step 4.1, secure Right Leg (D) to Front Support Bar (E) by using Screw (③) with Allen Wrench (①).

Step 4.2, secure Right Leg (D) to Seat Panel (B) by using Bolts (④) and Washers (⑤) with Allen Wrench (①).


Do not fully tighten the Screw and the Bolts.



With assistance from your adult partner, attach Side Support Bars (F) to the assembled part in Step 4 as shown above.

Then secure Side Support Bar (F) to both Left Leg (C) and Right Leg (D) by using Screws (③) with Allen Wrench (①).

Do not fully tighten the Screws.



With assistance from your adult partner, attach Backrest Panel (A) to the assembled part in Step 5 as shown above. Then:


Step 6.1, secure Backrest Panel (A) to Seat Panel (B) by using Bolts (④) and Washers (⑤) with Allen Wrench (①).

Step 6.2, secure Backrest Panel (A) to Side Support Bars (F) by using Screws (③) with Allen Wrench (①).

Step 6.3, secure Backrest Panel (A) to Seat Panel (B) by using Screws (②) with Allen Wrench (①).

Do not fully tighten the Screws and the Bolts.

Step 7



Inspect it and make sure all parts are adequately connected.

Stand the Dining Chair right side up.

Then proceed to tighten the Bolts and Screws in a sequential manner.

When tightening the Bolts and Screws, tighten sequentially.

DO NOT tighten any Bolts, Screws fully and then move on towards the next one.

If there are still wobbles, loosen the Bolts, Screws and execute this same process.

Adjust Pre-installed Levelers height for balance.

Your Dining Chair is ready to use.

This Dining Chair can only be used on a flat, level surface.