

## ASSEMBLY INSTRUCTION

Caution : You must read this before you proceed


### Care & Maintenance

- ⊗  • Not for commercial use. For residential use only.
- ✓  • Furniture may scratch floors. We recommend using furniture pads to protect your floors.
- ⊗  • Do not put hot items directly on furniture surface.
- ⊗  • Do not clean furniture with harsh cleansers or polish.
- ⊗  • Do not place furniture under direct sunlight.
- ⊗  • Do not place furniture near heating or cooling vents.
- ⊗  • Do not write on furniture without a padded barrier to protect the surface.
- ⊗  • Do not place furniture outside. For indoor use only.
- ⊗  • Stains may be removed with mild soap solution and damp cloth.
- ⊗  • Children should not climb or jump on the furniture.




- ✓  • Dust and pick-up spills using a clean, non-colored, lint-free cloth.

Please look in carton for hardware packs and legs.  
Sets often ship in multiple boxes and may arrive a day or two apart.

DINING CHAIR  
N768P427477



Parts List

Label	Picture	Description	QTY
A		Seat Cushion Frame	1
B		Back frame	1
C		Right leg	1
D		Left leg	1
E		Stretcher	2

## HARDWARE LIST


Label	Picture	Description	QTY
①		Bolt (M5/16" x50mm)	4+1
②		Bolt (M5/16"x40mm)	6+1
③		Spring Washer (12mm)	10+1
④		Flat Washer (19 mm)	10+1
⑤		Allen Wrench (M4)	1+1
⑥		Screw (4x35mm)	4+1
⑦		Spare Leveller	1

not included



## Assembly Preparation

Before Beginning Assembly:



- Read instructions, cover to cover-



- Have 2 adults on hand for assembly-



- Do not assemble on flooring of carpet-




- Assemble on a clean non-marring surface (packing foam)-



- Save all packaging until finished-


## Assembly Steps

### Overview




This chair has multiple parts and may require up to 30 minutes to assemble. To give you an overview of the chair parts, the above picture is provided to help you put the various parts into perspective. Please read through the instructions below to familiarize yourself with the parts and steps before assembly.

## Step 1



Attach Seat cushion A into Back frame B. Use bolt (2) , Spring washer (3) , Flat washer (4) and Allen key (5) . Do not full tighten..

## Step 2




Attach Right/Left leg C/D into Seat cushion A and Stretcher E into Right/Left leg C/D. Use bolt ①, Spring washer ③, Flat washer ④, Allen key ⑤. Do not full tighten. Use screw ⑥ correctly drilled hole and full tighten all hardware.

**AUTION :** When tightening these screws, tighten sequentially. DO NOT tighten any screw fully and then towards the next one. This would cause the frame to warp.


If there is still wobbles, loosen the screws and execute this same process. **WARNING!! IF IT IS NOT STABLE, IT COULD LEAD TO DAMAGING THE PRODUCT.**

### Step 3



After checking the chair, If no problem, pls tighten all the Bolts.  
Stand the Chair up .  
Place the chair on a **LEVEL SURFACE** to check for wobbles .

### Step 4



Your Chair is ready for use .  
This chair can only be used on a flat, level surface.