

Assembly Instructions

Caution : You must read this before you proceed

Care & Maintenance



- Not for commercial use. For residential use only.



- Furniture may scratch floors. We recommend using furniture pads to protect your floors.



- Do not put hot items directly on furniture surface.



- Do not clean furniture with harsh cleansers or polish.



- Do not place furniture under direct sunlight.



- Do not place furniture near heating or cooling vents.



- Do not write on furniture without a padded barrier to protect the surface.



- Do not place furniture outside . For indoor use only.



- Stains may be removed with mild soap solution and damp cloth.




- Children should not climb or jump on the furniture.






- Dust and pick-up spills using a clean, non-colored, lint-free cloth.

Please look in boxes for hardware packs and legs.

Dining Chair



Parts List

Label	Picture	Description	QTY
A		Backrest	1
B		Seat	1
C		Left Front Leg	1
D		Right Front Leg	1
E		Left Back Leg	1
F		Right Back Leg	1

Hardware

Label	Picture	Description	QTY
①		Bolt (M8X50mm)	12
②		Bolt (M8X40mm)	3
③		Spring Washer	12
④		Flat Washer	12
⑤		Allen Wrench	1

Assembly Preparation

Before Beginning Assembly:

X12
 X3
 X12
 X12

① ② ③ ④ ⑤

A B C D

E F



- Read instructions, cover to cover-



- Have 2 adults on hand for assembly-



- Do not assemble on flooring or carpet-




- Assemble on a clean non-marring surface (packing foam)-



- Save all packaging until finished-

Assembly Steps


Overview



This Chair has multiple parts and may require up to 30 minutes to assemble. To give you an overview of the Chair parts, the above picture is provided to help you put the various parts into perspective. Please read through the instructions below to familiarise yourself with the parts and steps before assembly.

Friendly reminder: Tighten all the screws after all holes are installed.

Step 1




Open the carton, and place all parts on a clean, non-marring surface.

Take out Backrest(A) and Seat(B).

Uncover the bottom cloth, and expose the frame. There are magic taps around the bottom of the seat frame.


Insert Seat(B) into Backrest(A) as shown, make sure the three holes at the bottom are aligned. Use Bolt(①), Spring Washer(③) and Flat Washer(④) with Allen Wrench(⑤) to tighten it.

Step 2




Take out Left Front Leg(C) and Right Front Leg(D).
Insert front legs into the slots at the front of the armrests as shown.
Use Bolt(②) with Allen Wrench(⑤) to lock it.
Do not fully tighten the Bolts.

Step 3




Align the holes at the bottom of the seat with those between the two front legs.
Use Bolt(①), Spring Washer(③) and Flat Washer(④) with Allen Wrench(⑤) to lock it.
Do not fully tighten the Bolts.
Repeat to assemble the other side.
Then fully tighten all the Bolts.

Step 4




Take out Left Back Leg(E) and Right Back Leg(F).
Insert the back legs into the slots at the bottom of the seat frame as shown.
Use Bolt(①), Spring Washer(③) and Flat Washer(④) with Allen Wrench(⑤) to tighten it as shown.

Step 5



Cover the bottom cloth of Seat (B) down and fasten the magic tap properly.



Place the Chair right side up and tested for stability.

Fully Tighten all the bolts.

Adjust the levelers on the legs to ensure chair stability.

Your Chair is ready for use.

This CHAIR can only be used on a flat, level surface.