




# Kitchen Cart

SKU N707P409087


Assembly instructions-Please keep for future reference




Important-Please read these instructions fully before starting assembly




**QUICKFIT:** Tighten quickfit until shoulder is flush with panel. Do not overtighten or undertighten.





**LOCK:** When fitting cam lock, ensure starting position is correct before you insert connecting quickfit.



Quickfit head should be in the centre of the cam lock when the two panels are joined. Cam lock should be inserted before quickfit.




Turn cam lock clockwise to tighten.









## friendly reminder








To avoid errors and confusion during the installation of accessories, use the type and quantity of hardware accessories according to the installation procedure described in the instructions. First, unroll the accessories bag and lay out the hardware accessories, cut holes in the side, and take out the hardware accessories

# Assembly Instructions

















# Parts List

NO.	PARTS	QTY
①		x1
②		x1
③		x2
④		x1
⑤		x1
⑥		x1
⑦		x1









NO.	PARTS	QTY
⑧		x1
⑨		x1
⑩		x1
⑪		x1
⑫		x1
⑬		x1
⑭		x1

# Parts List

NO.	PARTS	QTY
15		x2
16		x1
17		x2
18		x1
19		x1
20		x1
21		x2



NO.	PARTS	QTY
22		x2
23		x4
24		x2
25		x2
26		x2
27		x2
28		x2

# Hardware



<b>A</b> x16+1 Ø6x35mm 	<b>B</b> x16+1 Ø15x10mm 	<b>C</b> x47+2 M4x30mm 	<b>D</b> x4  D1                      D2		<b>E</b> x32+2 M3x12mm 	<b>F</b> x2 
<b>G</b> x2 	<b>H</b> x18+1 M8x30mm 	<b>I</b> x10 	<b>J</b> x2 	<b>K</b> x2 	<b>L</b> x20+2 M5x50mm 	<b>M</b> x1 
<b>N</b> x4 	<b>O</b> x12+1 M4x16mm 	<b>P</b> x4 	<b>Q</b> x1 	<b>R</b> x2   +1 M3x14mm	<b>S</b> x16+1 M3x16mm 	<b>T</b> x4+1 
<b>U</b> x1 	<b>V</b> x4 	<b>W</b> x7+1 M4x40mm 	<b>X</b> x8+1 M6x30mm 	<b>Y</b> x1 	<b>Z</b> x1 	


# Assembly Steps

1













2






Press the pull bar upward to detach the rail










L x2  
M5x50mm




H x2



H x4







L x2  
M5x50mm




H x4














L x8  
M5x50mm







H x8
















C x7  
M4x30mm




A small rectangular box containing the text 'C x7' and 'M4x30mm' above a detailed illustration of a screw with a Phillips head and a pointed tip.






W x7  
M4x40mm

A small rectangular box containing the text 'W x7' and 'M4x40mm' above a detailed illustration of a screw with a Phillips head and a pointed tip.







x2



x2




D2 x4




E x12






M3x12mm

















Disconnect  
Levers



When installing the slide rail, it should be inserted at the same time, and then pushed together












# Assembly Instructions

Caution : You must read this before you proceed

## Care & Maintenance

-  ● Not for commercial use. For residential use only.
  -  ● Furniture may scratch floors. We recommend using furniture pads to protect your floors.
  -  ● Do not put hot items directly on furniture surface.
  -  ● Do not clean furniture with harsh cleansers or polish.
  -  ● Do not place furniture under direct sunlight.
  -  ● Do not place furniture near heating or cooling vents.
  -  ● Do not write on furniture without a padded barrier to protect the surface.
  -  ● Do not place furniture outside . For indoor use only.
  -  ● Stains may be removed with mild soap solution and damp cloth.
  -  ● Children should not climb or jump on the furniture.
- 
-  ● Dust and pick-up spills using a clean, non-colored, lint-free cloth.