

# Assembly Instructions


Caution : You must read this before you proceed

## Care & Maintenance

	<ul style="list-style-type: none"><li>● Not for commercial use. For residential use only.</li></ul>
	<ul style="list-style-type: none"><li>● Do not put hot items directly on furniture surface.</li></ul>
	<ul style="list-style-type: none"><li>● Do not clean furniture with harsh cleansers or polish.</li></ul>
	<ul style="list-style-type: none"><li>● To obtain the longest lifespan of your outdoor products, minimizing exposure to direct sunlight is recommended.</li></ul>
	<ul style="list-style-type: none"><li>● Children should not climb or jump on the furniture.</li></ul>
	<ul style="list-style-type: none"><li>● Do not write on furniture without a padded barrier to protect the surface.</li></ul>
	<ul style="list-style-type: none"><li>● To obtain the longest lifespan of your outdoor products, avoid extended and lengthy exposure to rain, snow, and direct sunshine. Whenever possible cover the product and /or place under patio or awnings.</li></ul>
	<ul style="list-style-type: none"><li>● Stains may be removed with mild soap solution and damp cloth.</li></ul>
	<ul style="list-style-type: none"><li>● Keep away from sources of ignition.</li></ul>
	<ul style="list-style-type: none"><li>● Dust and pick-up spills using a clean, non-colored, lint-free cloth.</li></ul>




Please look in the Backrest Panel for hardware packs.

## DINING CHAIR



CAUTION: This Dining Chair is NOT a TOY.  
Keep your child / children at bay during the assembly process.  
Whenever lifting or moving the **Dining chair** and to prevent any damage to it, two adults may be needed to execute these actions.

## Part List:


Label	Picture	Description	QTY
A	 A rectangular, textured panel with a slightly curved top edge, shown in a perspective view.	Backrest Panel	1
B	 A thin, L-shaped metal or plastic panel, shown in a perspective view.	Left Leg Panel	1
C	 A thin, L-shaped metal or plastic panel, shown in a perspective view.	Right Leg Panel	1
D	 A thin, L-shaped metal or plastic panel, shown in a perspective view.	Back Left Leg panel	1
E	 A thin, L-shaped metal or plastic panel, shown in a perspective view.	Back Right Leg panel	1
F	 A long, thin, rectangular bar with slightly rounded ends, shown in a perspective view.	Support Bar	1
G	 A rectangular panel with a grid of horizontal slats, shown in a perspective view.	Seat Panel	1

# Hardware

Label	Picture	Description	QTY
①		Bolt (M6x55mm)	3
②		Screws (M6x60mm)	5
③		Screws (M6x80mm)	5
④		Allen Wrench	1

# Assembly Preparation

Before Beginning Assembly:



- Read instructions, cover to cover-



- Have 2 adults on hand for assembly-



- Do not assemble on flooring or carpet-




- Assemble on a clean non-marring surface (packing foam)-



- Save all packaging until finished-


# Assembly Steps

## Overview




This Dining Chair has multiple parts and may require up to 30 minutes to assemble. To give you an overview of the Dining chair parts, the above picture is provided to help you put the various parts into perspective. Please read through the instructions below to familiarise yourself with the parts and steps before assembly.

### Step 1



Unpack and place all parts on a clean, non-marring surface.

### Step 2




Place the Seat Panel (G) lie as shown in the picture above onto a clean, soft surface to avoid any scratches or damage to the product. With assistance from your adult partner(s):

Attach the Back Left Leg panel(D) to the Seat Panel(G), using Screw (2) and the Allen Wrench (4) as shown above.

**DO NOT fully tighten the Screws at this time.**

### Step 3




Place the step 2 lie as shown in the picture. With assistance from your adult partner(s):

3.1 Attach the Left Leg Panel (B) to Back Left Leg panel(D) of the Step2, using Bolts (1) and the Allen Wrench (4) as shown above.

3.2 Attach the Left Leg Panel (B) to Seat Panel(G) of the Step2 & Support Bar(F), using Screws (3) and the Allen Wrench (4) as shown above.

**DO NOT fully tighten the Bolts and Screws at this time.**


**Step 4**



Place the step 3 lie as shown in the picture. With assistance from your adult partner(s): Attach the Backrest Panel(A) to Back Left Leg panel(D) of the Step3, using Screws (2) and the Allen Wrench (4) as shown above.

**DO NOT fully tighten the Bolts and Screws at this time.**


**Step 5**



Place the step 4 lie as shown in the picture. With assistance from your adult partner(s): Attach the Back Right Leg Panel (E) to the Seat Panel(G) & Backrest Panel (A) using Screws (2) and the Allen Wrench (4) as shown above.

**DO NOT fully tighten the Bolts and Screws at this time.**

**Step 6**




Place the step 5 lie as shown in the picture. With assistance from your adult partner(s): 6.1 Attach the Right Leg Panel (C) to Back Right Leg panel(E) of the Step5, using Bolts (1) and the Allen Wrench(4) as shown above.

6.2 Attach the Right Leg Panel (C) to Seat Panel(G) & Support Bar (F) of the Step5, using Screws (3) and the Allen Wrench (4) as shown above.

**DO NOT fully tighten the Bolts and Screws at this time.**

### **Step 7**



Turn the Chair right side up.

Inspect the Chair and make sure all parts are adequately connected.

In a sequential manner, tighten all Screws and Bolts at all joints.


With assistance from your adult partner, adjust the Levelers to the desired height to avoid wobbles.

**CAUTION: When tightening these screws and bolts, tighten sequentially.**

**DO NOT tighten any screw or bolt fully and then move towards the next one. This could cause the frame to warp.**

**WARNING!! IF THE Chair IS NOT STABLE , IT COULD LEAD TO DAMAGING THE PRODUCT.**

### **Step 8**



Your **Dining chair** is ready to be used.

This - **Dining chair** can only be used on a flat, level surface.