




WALK-IN TUB

INSTALLATION INSTRUCTIONS AND OWNER'S MANUAL



Website: www.casainc.com
Contact Phone Number: 888-257-3857
Service Contact : service@casainc.com

TABLE OF CONTENTS

Introduction..... 1

Installation

Installation instruction..... 2

Precautions for installation..... 3

Operation

Accessories instruction..... 4

Care and Maintenance

Care and Maintenance procedures..... 7

Troubleshooting guide..... 8

Pre-installation Instructions

WARNING: When using this tub, follow these basic precautions:

- Avoid the risk of electrical shock. Connect only to a circuit protected by a ground-fault circuit-interrupter(GFCI). Grounding is required; All electrical connections should be made by a licensed electrician, in accordance with requirements of national electrical codes and procedures.

- INSTALLER/OWNER BEARS ALL RESPONSIBILITY TO COMPLY WITH ALL STATE AND LOCAL BUILDING CODES WHEN INSTALLING THIS UNIT

TESTING YOUR WALK-IN TUB BEFORE INSTALLATION BY FOLLOWING PROCEDURES:

1. Before unpack the unit, please inspect the carton carefully for any damage. Any damage, please take a picture or record all damage carefully. If necessary, contact your dealer/distributor immediately to file a freight claim.
2. Unpack the carton, then inspect the carton carefully for any damage and check if all the spare parts are there. If there is any damage, please take a picture or record all it carefully. If necessary, contact your dealer/distributor immediately.
3. Water test before installation. Although all our walk-in tub are water tested before they leave our factory, there may be some loose of the hose connections due to the transport.
 - a. Place the tub on a flat surface in an area where it may be drained after testing.
 - b. Check if there is any loose of the connection system.
 - c. Close the door, fill the tub with water to the overflow and allow standing for a few minutes to inspect the tub for leaks.
 - d. Insert the plug, start all the function for few minutes (which includes the functions of massage, air bubble, underwater light, ozone sterilization, aroma and so on), inspect the tub completely any defect must be reported to your dealer/distributor prior to installation in order to have it covered under warranty.

IMPORTANT: Failure to follow the pre-installation instruction and water test the bathtub before installation, manufacturer will not be liable for the removal or installation of the bathtub.


Installation instruction

1. The bottom of the tub is installed the leveling feet.

Note: It is important that all leveling feet are completely touching the floor. If fail to do so, it will influence the water recycle system and drain the water completely.





2. Connect your drain hose and the floor drain



3. The way to connect the hot/cold water hoses to your house's water connection


Notice: Red water hose is for the hot water, blue water hose is for the cold water.




Before connect bathtub water inlet pipe, first open water pipe for a period of time, then put filter screen to ensure that the debris will not enter the bathtub pipe. So that we can effectively extend the life of the fitting.

4. How to connect the electricity?

Connect the power lead (3 wires marked with **L** (Live wire), **N** (Neutral wire) And \oplus (Ground wire) on the motor (or power box) to the power supply indoor accordingly.



Make sure the ground is connected: one side of the ground should be connected to the ground terminal of the motor and the stainless steel frame; the other side should be connected to the ground wires of the plug.



Precautions for installation

INSTRUCTIONS PERTAINING TO RISK OF FIRE, ELECTRIC SHOCK, OR INJURY TO PERSONS.


WARNING: When using this unit, follow these basic precautions:

1. Do not permit children to use this unit unless an adult closely supervises them at all times. Supervision is also required when an elderly or handicapped individual uses whirlpool bath.
2. Use this unit only for its intended use as described in this manual. Do not use attachments not recommended by the manufacturer.
3. Do not operate this unit without the suction cover over the suction fitting. This suction cover is a safety device that reduces the potential hazard of hair or body entrapment. Keep hair and body away from suction cover when the pump is running
4. Never operate electrically connected devices in or near the bath. No electric appliances should be within 5 feet/1.5 meters of this bathtub (such as hair dryers, lamp, telephone, radio, television and so on.)
5. Never drop or insert any object in any opening within the whirlpool
6. For the early months of pregnancy, pregnant or possibly pregnant women should limit whirlpool water temperature to 100°F(38°C), because the excessive water temperatures have a high potential for causing fetal damage.
7. The use of drugs or alcoholic beverages before or during whirlpool use may lead to unconsciousness with the possibility of drowning.
8. Person with a medical history of heart disease, low or high blood pressure, circulatory system problems or diabetes should consult a physician before using a whirlpool.
9. Persons using medication should consult a physician before using a whirlpool since medication may induce drowsiness while other medication may affect heart rate, blood pressure and circulation
10. The thermostatic mixer can maintain the temperature of the water input, please use carefully according to the operating instruction to avoid the scald or catch a cold.
11. The water temperature in a whirlpool should never exceed 104°F (40°C). Temperatures between 100°F (38°C) and 104°F (40°C) are considered safe for healthy adults. Usage time should be limited to approximately 30 minutes, followed by a shower to cool down. Lower water temperatures are recommended for extended use (exceeding 10-15 minutes) and are definitely recommended for younger children. If you become nauseous, dizzy or develop a headache, get out at once and cool down. Get medical attention if symptoms persist. Check with a physician before using whirlpool again.
12. This unit must be connected to a circuit that is protected by a Ground Fault Circuit Interrupter(GFCI). The GFCI should be provided and installed by a licensed electrician and tested on a regular basis (at least monthly). To test the GFCI push the test button. TheGFCI should interrupt the power. Push the reset botton and the power should be restored. if the GFCI fails to operate in this manner there is a possibility of an electric shock , do not operate this unit. disconnect the unit and have the problem corrected by a licensed electrician before using.
13. Maintenance window for product maintenance, it is recommended that professional maintenance personnel operate. The maintenance window is closed with a magnet. the person who wearing medical devices such as pacemakers, Please keep away from it.

CAUTION: DO NOT USE HARSH ABRASIVES OR SOLVENTS TO CLEAN THIS PRODUCT.

SAVE THESE INSTRUCTIONS

● GD-370 Control Panel Operation:




1. Power on/off

To turn power on, press "Power on/off" key. It will start the system and the functions' icon will be showed on the display. You can choose the function as you want. Press this key again then power off.

2. Operation

Press "SET" key each time, then symbol "◀" will point to each function icon one by one. You can select the function you want or close the function by pressing the "OK" key. Please refer to the right picture and choose the function accordingly:



 Description	The water pump is limited by water level ,it only be launched the surfing function under the condition of water level .If short of water, the "☒" will flicker, water pump cannot start .The pump will be turned off every time when it worked 60 minutes.
	Only the surfing function on, the heating function can be launched, and control by the preset temperature.
	Only the radio/AUX function off ,the preset temperature can be changed by pressing (△) or (▽) within 20°C--45°C(default 38°C). When the water temperature reach to the preset temperature ,it will turn into constant temperature.
	The air bubble function will be turned off automatically every 60minutes.
	The ozone function : The working time is 15 minutes.
	When turn on radio function, press the button again then it will turn on AUX function.Volume adjustment: the volume can be adjusted by press "△" or "▽", and the screen will display volume DB number accordingly
	Automatic keyboard locking : If no action on the keyboard for 2 minutes, the screen will shows lock and (🔒) icon which means the keyboard is locked automatically, and press (🔥) can be unlocked.

● Hydro massage flow rate control:

Hydro massage is controlled alternatively by water force. You can adjust it manually. Rotate the knob clockwise, then the water column strength smaller; rotate the knob anticlockwise, then the water column strength stronger. Or you can press the nozzle to control water column strength.



● Faucet:

Water pressure
massage adjust

Three-piece set faucet

Switch marked with "H" is hot water switch;
Switch marked with "C" is cold water switch;
Switch marked with icons is transferable switch which can be rotated to waterfall or sprinkling style.



● Multi-function handheld shower with back flow protector :

Rotate the shower head shell can adjust the water pattern as follow:

- Inner water column
- Middle water column
- External water column



● Drainage:

Rotate the cover clockwise to close the drain.
Rotate the cover anticlockwise to open the drain

When the water is over the maximum water level, the excess water will be drained by overflow.

Notice:

When the overflow cover is faulty or it is hard to rotate, please upward the chain to draining the water by hand.





● **Aromatherapy box:**

Follow the indicator on the red cap of Aromatherapy box to open or close this function. The aromatherapy liquid will enter the bathtub through the air bubble function.

Notice/Caution:

Please always keep the aromatherapy box screw tightly to avoid electric shock.

When the Aroma is used up, please change the new one as follow steps:



● **Door lock:**

Steps to close the door


Close the door, press the door handle downward

Steps to open the door


Lift up the handle, open the door

Notice:

1. The water tight system is well-design and professional. You do not need to press door handle downward with so much strength, so that you can lift up the door easily when you open the door.
2. Before filling the water into the tub, please make sure that the bathtub door is locked tightly. Failure to do so will result in water leakage.
3. Before opening the door lock, please make sure that the water has been drained completely.



close



open

Care and Maintenance

Regular care of your walk-in tub with the hydro massage system will keep it clean and working at its best.

Pump and pipe circulation systems should be flushed before first use and on a monthly basis when product is under normal use. Below are the recommended procedures for cleaning:

1. Do not run the jet massage system dry.
2. Fill the tub with hot water 2-3 inches above the jets and add 2-3 teaspoons of low foaming detergent such as dishwashing machine detergent.
3. Turn on jet massage system and run for 10 minutes.
4. Drain tub completely.
5. Fill tub with cold water above jets.
6. Turn on jet massage system and run for 15 minutes.
7. Drain tub completely.
8. Cleaning the “suction cover”: Clean and remove any hair or lint from the suction cover. On a monthly basis, unscrew the suction cover and clean away any hair, lint or debris from the cover and housing, then remount the cover in place. Some suction covers are not designed to be removed; only suction covers that have screws on the cover, visible from the inside of the tub, can be removed. Never operate the unit with the safety suction cover off. Do not use abrasive cleaners as they will scratch and dull the surface. Use a mild liquid household detergent cleaner. Plaster can be removed using a wooden stick.
9. Do not use metal scrapers, wire brushes, water barrier wallboard or other harsh abrasive tools. Usually a mild detergent will remove construction debris. More stubborn debris may be removed with denatured alcohol. Light scratches and dulled areas may be restored to original luster by rubbing with an automotive type cleaning compound.

Care and Maintenance

SYMPTOMS	PROBLEMS	SOLUTIONS
Water pump will not start.	<ol style="list-style-type: none"> 1. Air hose connected to the pneumatic switch is loose; 2. Pneumatic switch does not work flexible; 3. Disconnected to the power or defective wiring; 4. There are some debris stuck the pump impeller; 5. Water level does not reach the minimum water level of the bathtub; 	<ol style="list-style-type: none"> 1. Tighten the connection of air hose and pneumatic switch; 2. Adjust the pneumatic switch; 3. Insert the plug; 4. Clean the debris; 5. Inflow water until it reaches the minimum water level of the bathtub.
Door leaks slightly	<ol style="list-style-type: none"> 1. Door lock is not closed tightly; 2. There is some debris on the door seal. 	<ol style="list-style-type: none"> 1. Close the door lock tightly; 2. Clean the debris on door seal.
Computer control panel does not work	<ol style="list-style-type: none"> 1. Disconnected to the power; 2. Poor contact plug. 	<ol style="list-style-type: none"> 1. Connect the power; 2. Insert the plug again.
Cannot control the hydro massage flow rate	<ol style="list-style-type: none"> 1. Power is not normal (Low voltage); 2. Pneumatic switch does not work; 3. Air hose is not connected tightly. 	<ol style="list-style-type: none"> 1. Insert the plug tightly; 2. Adjust pneumatic switch; 3. Connect air hose tightly.
Water hose leaks	<ol style="list-style-type: none"> 1. Rubber ring is not good; 2. Screw nut is not tightened, the connection is not good; 	<ol style="list-style-type: none"> 1. Change a new rubber ring; 2. Tighten screw nut and make sure its connection is good.