

USER MANUAL

Thank you support!

Thank you for choosing our collapsible wagon.
We hope it brings you lasting convenience and reliability.
We are always here to help and value your satisfaction.
Enjoy your new wagon!



WARNING

Immediate Discontinuation: Discontinue use immediately if any defect is found.

Personal Safety: Wear gloves during assembly, installation, or disassembly to protect against moving parts.

Intended Use: This wagon is designed for cargo transport only. It must never be used to transport children or adults under any circumstances.

Load & Environment: Always stay within the recommended weight capacity to ensure safety and prevent product failure. Avoid prolonged exposure to direct sunlight, water, or moisture. If the wagon gets wet, dry it thoroughly immediately.


Proper Handling: For optimal performance and durability, use on level ground with secure footing and avoid rough, uneven, or icy terrain. Assemble and fold with care, avoiding excessive force to prevent damage. A slight odor from the tires upon unboxing is normal and harmless.

1.Parts Checklist ●●●



2.Assemble&Use ●●●

Step 1: Take out all cart accessories from the carton.
Push 4 wheels into shaft securely.



Step 2: Hang the two insulated bags on the D-ring on the side of the frame.




1

Step 3: Pull handle out to extend..




Step 4: Assemble Rod Holders

Align the bolt with the hole on the frame, insert it, and tighten the nut.
(You can use a screwdriver to easily align the bolt with the hole and insert it.)



Step 5: Adjust the chair frame height using the knob.



2