



ASSEMBLY INSTRUCTIONS
COASTER FINE FURNITURE



Fine Furniture for every stage of life

122178
Counter Height
Dining Table Base

ITEM: 122178

ASSEMBLY INSTRUCTIONS

ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.




ASSEMBLY TIME

15 MINUTES

PARTS IDENTIFICATION

A LEG SUPPORT FRAME




1PC

B LEG



4PCS

C DISC WITH BOLT



4SETS

HARDWARE IDENTIFICATION

1 BOLT
(M8 x 60MM -RBW)



8PCS

2 LOCK WASHER
(M8 x 13MM - RBW)



8PCS

3 FLAT WASHER
(M8 x 22MM - RBW)



8PCS

4 ALLEN WRENCH
(M5 x 65MM -BLK)




1PC

ITEM: **122178**


ASSEMBLY INSTRUCTIONS

STEP 1



BOTTOM VIEW

STEP 2




ITEM: **122178**

ASSEMBLY INSTRUCTIONS




STEP 3




STEP 4
COMPLETE



NOTE : GLASS TOP NOT INCLUDED



ITEM: 122178



Note: Dimension tolerance $\pm 5\%$