Assembly Instructions

ITEM NO.: 194S8344BLK/BRW/BUE/GRY-3PWHM
Power Double Reclining Sofa with Center Drop-Down Cup Holders, Power Headrests, Storage Arms ,Cup holders, Reading Lights, Wireless Charger, Air Massage, Heat, LED Lighting and Charging Ports

Note: Do not use power tools for assembly. Power tools increase the risk of over tightening which leads to splitting or cracking the wood.

COMPONENT LIST

No	Drawing	Description	Qty
A		SEAT	1 PC
B		LSF BACK REST	1 PC
C		MIDDLE BACK REST	1 PC
D		RSF BACK REST	1 PC
E		ADAPTOR	2 PCS

Step #1





Step #2





Step #3



Step #4



1. LED light button:
   Grade 1: 50%
   Grade 2: 75%
   Grade 3: 100%
   OFF
2. USB PORT
3. USB Type C
4. Massage
   Grade 1: Slow then stop and repeat
   Grade 2: Fast then stop and repeat
   Grade 3: Fast & continuous and repeat
   Grade 0: TURN OFF
5. 1 Heating
6. Open recliner
7. Close recliner
8. Open headrest
9. Close headrest
10. Home Button



1. USB PORT
2. USB Type C
3. Massage
   Grade 1: Slow then stop and repeat
   Grade 2: Fast then stop and repeat
   Grade 3: Fast & continuous and repeat
   Grade 0: TURN OFF
4. 1 Heating
5. Open recliner
6. Close recliner
7. Open headrest
8. Close headrest
9. Home Button

COMPLETED



Care Instructions for Leather Match PVC Furniture:

In order to maintain the original appearance of your leather match PVC, please follow simple care procedures below:

- Avoid exposing furniture directly to sunlight or heating and air conditioning outlets. Sunlight and/or exposure to heating and air conditioning outlets will fade/damage leather match PVC.
- Vacuum or wipe with a soft cloth to remove dust.
- Hardware may loosen over time. Periodically check to make sure all connections are tight. Re-tighten if necessary.

For items used on wooden floor, hard surfaces or carpets, it is recommended to install protective pads under all legs and supports to prevent damage/scratches and discoloration.