

# ASSEMBLY INSTRUCTIONS

ITEM#: HL6013

## IMPORTANT SAFETY INSTRUCTIONS:

*Before assembly the lamp. Please read the following precautions and instructions thoroughly.*

The Lamp is for indoor and dry area use only.

This Lamp uses 110-120 volts electric outlet only.

This Lamp fits in polarized outlet one way only. Polarized plug has one blade wider than the other, it is safety feature to reduce the hazard of electrical chock.

The electrical wire is connected continuously through the poles, Do not pull wires or over forced during unpacking

The lamp produces very high temperature on light bulb, always unplug electrical cord and wait for the bulb to cool down before replacing bulb.

## ASSEMBLY INSTRUCTIONS:

### NOTE:

Carefully unpack the packaging and inspect all parts, place them on a flat and dry surface, avoid hard surfaces that would damage the lamp finish.

**\*DO NOT PLUG INTO THE ELECTRICAL OUTLET WHEN INSTALLING**

- 1). Assembly Lamp Base
  - Take off the bolt (B) and washers (C) (D) from the end lamp pole tube (F), connect the lamp pole metal tube (F) onto the base (E) by align the tube (F) and pin to the smaller hole on the base hardware washer hole, insert bolt (B) with washers (C) and (D) through bottom of the base to the tube (F), use wrench (A) provided tight up the bolt (B)
- 2). Assembly Lamp Arches
  - Insert the lamp arc pole (J) through arc tube nut cap (I) into lamp pole (H), tighten the nut cap (I)
  - Take off screw (G) from the pole (H) end tube, insert the arc tube (H) into the lamp pole tube (F), line up the small holes on both (F) and (H), secure tighten with screw (G) use your screwdriver
  - Place lamp in standing position
- 3). Assembly Lamp Shades and Bulbs
  - ( Use dimmable LED 20W max or 100W max incandescent bulb. \* One dimmable LED bulb included )
  - Take off the ring cap (L) from bulb socket (K)
  - Place the shade (M) onto the arch bulb socket (K), secure tight with the ring cap (L)
  - Screw on the bulb to the bulb socket (K). \* One dimmable LED bulb Included
  - Insert the plug into the electric wall outlet, the lamp is ready to use.
- 4). Adjust the lamp arch length
  - ( \*Always unplug the wire before the adjustment . Do not over force pulling wire during the adjustment )
  - Loose lamp arc tube nut cap (I)
  - To retract the lamp arch length, push the arc pole (J) inward slightly each time while pull the wire from lower lamp tube (F)
  - To extend the lamp arch length, pull the arc pole (J), stop at reach end of the maximum length
  - Secure tight lamp arc tube nut cap (I)

