




LINON HOME DECOR PRODUCTS, INC.

ASSEMBLY INSTRUCTION

**ARDMORE CORNER NOOK SET
MODEL 90305WHT-B-KD-U**



WE ARE HERE TO HELP!

WE DO OUR BEST TO INSURE THAT YOUR FURNITURE ARRIVES IN EXCELLENT CONDITION. IN THE EVENT THAT A PART IS DAMAGED OR MISSING, LINON HOME DECOR WILL BE HAPPY TO PROVIDE YOU WITH REPLACEMENT PARTS, AT NO CHARGE, WITHIN 30 DAYS OF PURCHASE, PROVIDING THE PARTS ARE AVAILABLE IN OUR WAREHOUSE AND THE ITEM PURCHASED IS PART OF OUR CURRENT INVENTORY. IN ORDER TO RECEIVE SPARE PARTS, AT NO CHARGE, YOU MUST PROVIDE PROOF OF PURCHASE WITHIN 30 DAYS.

IF YOU NEED ASSISTANCE WITH ASSEMBLY OR REPLACEMENT PARTS, PLEASE CALL LINON CUSTOMER SERVICE, PRIOR TO RETURNING THE ITEM TO THE STORE.

OUR OFFICE IS OPEN MONDAY - FRIDAY 9AM - 5PM, EASTERN STANDARD TIME.

OUR TOLL FREE CUSTOMER SERVICE- NUMBER IS: 1-800-262-1852.






OR VISIT OUR WEB SITE WWW.LINON.COM TO ORDER SPARE PARTS AND FOR CARE INSTRUCTIONS ON YOU' RE NEWLY PURCHASED FURNITURE.

**LINON HOME DECOR PRODUCTS, INC.****HARDWARE PACKAGE COUNT (CORNER BENCH)**

OPEN HARDWARE PACKAGE ON A FALT SURFACE COVERED WITH NEWSPAPER. COUNT EACH PIECE OF HARDWARE TO MATCH THE QUANTITY NUMBER IN THE HARDWARE IDENTIFICATION COLUMN. CALL CUSTOMER SERVICE IF ANY PARTS ARE MISSING. FOLLOW THE LETTER IDENTIFICATION WHEN READING THE ASSEMBLY DRAWING "A" THROUGH "E".

HARDWARE IDENTIFICATION

FERRAGEM: 300*200*40

A		WOOD DOWEL 1-3/16"LONG 8*30mm	32
B		SCREW 1-2"LONG 5*50mm	20
C		PLASTIC PIN	4
D		SCREW 1"LONG 5*25mm	36
E		WOOD HOLE COVER	8

IF ANY PARTS ARE MISSING OR DAMAGED IN THIS PACKAGE LINON HOME DECOR WILL BE HAPPY TO PROVIDE YOU WITH REPLACEMENT PARTS, AT NO CHARGE, WITHIN 30 DAYS OF PURCHASE, PROVIDING THE PARTS ARE AVAILABLE IN OUR WAREHOUSE AND THE ITEM PURCHASED IS PART OF OUR CURRENT INVENTORY. **IN ORDER TO RECEIVE SPARE PARTS, AT NO CHARGE, YOU MUST PROVIDE PROOF OF PURCHASE WITHIN 30 DAYS.**

CALL US TOLL FREE AT 1-800-262-1852. OR VISIT OUR WEB SITE WWW.LINON.COM TO ORDER SPARE PARTS AND FOR CARE INSTRUCTIONS ON YOU' RE NEWLY PURCHASED FURNITURE.



**LINON HOME DECOR PRODUCTS, INC.****SELECT THE LAYOUT OF THE BENCH**

THIS ITEM REVERSIBLE AND CAN BE INSTALLED EITHER WITH THE LARGE BENCH AT YOUR LEFT HAND SIDE (LEFT SIDE INSTALLATION) OR WITH THE LARGE BENCH AT YOUR RIGHT HAND SIDE (RIGHT SIDE INSTALLATION).

THIS INSTRUCTION IS MADE FOR RIGHT HAND INSTALLATION.

IF YOU SELECT THE LEFT HAND INSTALLATION THEN YOU HAVE TO SWITCH ALL THE PARTS LOCATED AT RIGHT PART (09, 11, 12, 13 AND 15) TO LEFT PART AND THE PARTS LOCATED AT LEFT PART (02, 04, 05, 07 AND 16) TO RIGHT PART.

ATTENTION: OUTSIDE LEGS #06 AND #08 PLUS CENTRAL PIECES (1, 3, 10, 14 AND 19) REMAIN UNCHANGED.


**RIGHT SIDE INSTALLATION****LEFT SIDE INSTALLATION**

NOTE: BEFORE STARTING THE ASSEMBLY PROCESS, ALL PARTS SHOULD BE SEPARATED ACCORDING TO THE ITEM THEY BELONG TO. FOR BETTER IDENTIFICATION OF ALL PARTS, PLEASE USE PART IDENTIFICATION LIST BELOW TO THE CORNER BENCH. THE PART IDENTIFICATION LIST ON PAGE 10 FOR THE TABLE AND THE PART IDENTIFICATION LIST ON PAGE 13 FOR THE BENCH (SIMPLE).

PARTS IDENTIFICATION

01-MIDDLE LEGS (RIGHT AND LEFT)
02-SINGLE BENCH FRONT AND BACK RAILS
03-CENTER BACK PANEL
04-SINGLE BENCH STORAGE BOTTOM
05-SINGLE BENCH BACK REST
06-LEFT OUTSIDE LEG
07-SINGLE BENCH SEAT COVER
08-RIGHT OUTSIDE LEG
09-DOUBLE BENCH FRONT AND BACK RAILS
10-CORNER TOP PANEL



11-DOUBLE BENCH STORAGE BOTTOM
12-DOUBLE BENCH BACK REST
13-DOUBLE BENCH SEAT COVER
14-CORNER SHELF
15-TOP RAIL FOR DOUBLE BACK REST
16-TOP RAIL FOR SINGLE BACK REST
17-RAIL
18-STRETCHER
19-SUPPORT

**RIGHT SIDE INSTALLATION**


**LINON HOME DECOR PRODUCTS, INC.****STEP 1)**

1.1 INSERT (28) WOOD DOWELS (A), (04) PLASTIC PIN(C), (20) SCREWS(D) INTO HOLES LOCATED ON EDGES OF THE FOLLOWING PARTS AS SHOWN IN FIGURE 1:

- DOUBLE BENCH FRONT AND BACK RAILS #9
- SINGLE BENCH FRONT AND BACK RAILS #2
- SINGLE BENCH BACK REST #5
- DOUBLE BENCH BACK REST #12
- DOUBLE BENCH SEAT COVER #13
- CORNER SHELF #14
- SINGLE BENCH SEAT COVER #7
- MIDDLE LEGS (RIGHT AND LEFT) #1
- LEFT OUTSIDE LEG #6
- RIGHT OUTSIDE LEG #8
- RAIL #17
- STRETCHER #18

**FIGURE 1**

RAILS SHOULD BE
ASSEMBLED ON THE
SIDE OF LEG #1
(LEFT AND RIGHT),
#6 (RIGHT), #8 (LEFT).





STEP 2)

- 2.1 PLACE MIDDLE LEG #1 ON FLOOR .ATTACH SINGLE BENCH FRONT AND BACK RAILS #2 (2X) TO MIDDLE LEG #1, INSERT (02) WOOD DOWELS(A) INTO HOLES LOCATED ON THE MIDDLE LEG #1, AS SHOWN IN FIGURE 2.
- 2.2 INSERT SINGLE BENCH STORAGE BOTTOM #4 THROUGH GROOVE LOCATED ON SINGLE BENCH FRONT AND BACK RAILS #2, AS SHOWN IN FIGURE 2.
- 2.3 STILL WITH MIDDLE LEG #1 PLACED ON FLOOR. ATTACH SINGLE BENCH BACK REST #5 TO MIDDLE LEG #1. AFTER THAT PROCEED SCREWING USING PRE-DRILLED HOLES AS GUIDE. USING (02) SCREWS (B) AND A PHILLIPS HEAD SCREWDRIVER (NOT PROVIDED), AS SHOWN IN FIGURE 2.
- 2.4 REMEMBER THAT LEG #1 IS NOT SECURED IN ITS PLACE YET SO HOLDING IT TIGHT TO PARTS #5, #2 AND #4, INSERT THE SINGLE BENCH SEAT COVER #7 THROUGH GROOVE LOCATED ON SINGLE BENCH BACK RAIL #2 AND SINGLE BENCH BACK REST #5, THEN ATTACH LEG #6 TO PIECES PREVIOUSLY ATTACHED ON MIDDLE LEG #1. AFTER THAT PROCEED SCREWING USING PRE-DRILLED HOLES AS GUIDE, USING (04) SCREWS (B) AND A PHILLIPS HEAD SCREWDRIVER (NOT PROVIDED), AS SHOWN IN FIGURE 2.





FIGURE 2

**STEP 3)**

- 3.1 PLACE MIDDLE LEG #1 ON FLOOR. ATTACH DOUBLE BENCH FRONT AND BACK RAILS #9 TO MIDDLE LEG #1. AFTER THAT PROCEED SCREWING USING PRE-DRILLED HOLES AS GUIDE, USING (02) SCREWS (B) AND A PHILLIPS HEAD SCREWDRIVER (NOT PROVIDED), INSERT (02) WOOD DOWELS (A) INTO HOLES LOCATED ON THE MIDDLE LEG #1. AS SHOWN IN FIGURE 3.
- 3.2 INSERT DOUBLE BENCH STORGE BOTTOM #11 THROUGH GROOVE LOCATED ON DOUBLE BENCH FRONT AND BACK RAILS #9, AS SHOWN IN FIGURE 3.
- 3.3 STILL WITH MIDDLE LEG #1 PLACED ON FLOOR. ATTACH DOUBLE BENCH BACK REST #12 TO MIDDLE LEG #1. AFTER THAT PROCEED SCREWING USING PRE-DRILLED HOLES AS GUIDE, USING (02) SCREWS (B) AND A PHILLIPS HEAD SCREWDRIVER (NOT PROVIDED), AS SHOWN IN FIGURE 3.
- 3.4 REMEMBER THAT LEG #1 IS NOT SECURED IN ITS PLACE YET SO HOLDING IT TIGHT TO PARTS #9, #11 AND #12, INSERT THE DOUBLE BENCH SEAT COVER #13 THROUGH GROOVE LOCATED ON DOUBLE BENCH BACK RAIL #9 AND DOUBLE BENCH BACK REST #12, THEN ATTACH LEG #8 TO PIECES PREVIOUSLY ATTACHED ON MIDDLE LEG #1. AFTER THAT PROCEED SCREWING USING PRE-DRILLED HOLES AS GUIDE, USING (04) SCREWS (B) AND A PHILLIPS HEAD SCREWDRIVER (NOT PROVIDED), AS SHOWN IN FIGURE 3.

**FIGURE 3**



LINON HOME DECOR PRODUCTS, INC.

STEP 4)

- 4.1 ATTACH CORNER SHELF #14 TO MIDDLE LEGS #1 (RIGHT AND LEFT) INSERTING WOODEN DOWELS LOCATED ON CORNER SHELF EDGE INTO HOLES LOCATED ON SIDE OF MIDDLE LEGS. SECURE WITH (04) SCREWS (B) USING A PHILLIPS HEAD SCREWDRIVER (NOT PROVIDED). AS SHOWN IN FIGURE 4.
- 4.2 INSERT (08) WOOD HOLE COVERS (E) INTO HOLES LOCATED ON LEFT AND RIGHT OUTSIDE LEGS #6 AND #8. AS SHOWN IN FIGURE 4.




FIGURE 4

STEP 5)

- 5.1 ATTACH CENTER BACK PANEL TO SIDE OF MIDDLE LEGS #1 (RIGHT AND LEFT).
- 5.2 SECURE USING (08) SCREWS (D) AND PHILLIPS HEAD SCREWDRIVER (NOT PROVIDE), AS SHOWN IN FIGURE 5.




FIGURE 5



LINON HOME DECOR PRODUCTS, INC.

STEP 6)

- 6.1 ATTACH TOP CORNER TOP PANEL #10 TO TOP OF CENTER BACK PANEL #3, USING (02) SCREWS (D) AND PHILLIP HEAD SCREWDRIVER (NOT PROVIDED). AS SHOWN IN FIGURE 6.
- 6.2 ATTACH TOP RAIL FOR SINGLE BACK REST #16 TO UPPER EDGE OF SINGLE BENCH BACK REST #5, AND ATTACH TOP RAIL FOR DOUBLE BACK REST #15 TO UPPER EDGE OF DOUBLE BACK REST #12 USING PRE-DRILLED LOCATED ON BACK OF PANELS #5 AND #12 AS GUIDE, WITH (04) SCREWS (D) USING PHILLIPS HEAD SCREWDRIVER (NOT PROVIDE), AS SHOWN IN FIGURE 6.




FIGURE 6



LINON HOME DECOR PRODUCTS, INC.

STEP 7)

7.1 ATTACH SUPPORT #19 TO THE BACK OF CENTER BACK PANEL #03, USING PRE-DRILLED LOCATED ON BACK OF PANELS #3 AS GUIDE, WITH (02) SCREWS (D) USING PHILLIPS HEAD SCREWDRIVER (NOT PROVIDE), AS SHOWN IN FIGURE 7.





FIGURE 7

USING HELP PLACE THE CORNER BENCH IN ITS FINAL POSITION IN WHICH IT WILL BE USED.



PERIDIOCALLY CHECK ALL CONNECTIONS FOR TIGHTNESS



LINON HOME DECOR PRODUCTS, INC.

LIMITED 6 MONTHS WARRANTY

WHAT IS COVERED

This product is covered under our manufacturer's 6 months limited warranty (Linon Home Décor Products). To ensure your complete satisfaction, this warrants to the original purchaser that the Linon supplied item is free from defects in material and workmanship, as of the date of purchase, and that it will, under normal use and proper care, remain so for six months after the date of purchase.

Replacement of missing or initially defective parts will be sent, at no charge, for a period of 30 days from the date of purchase with valid proof of purchase providing the parts are available in our warehouse and the item purchased is part of our current inventory.

WHAT IS NOT COVERED

It remains the customer's responsibility for freight and packaging charges to and from the customer service center. Labor and material charges to remove or replace parts under this warranty are not covered.

This warranty does not cover: Furniture used for commercial purposes, failures caused by improper installation assembly or by improper care, unreasonable or abusive use, freeze damage, acts of God, rust, purchased parts or return freight and packaging charges. Proof of purchase (dated register receipt) is required for warranty claims.

HOW TO OBTAIN SERVICE

For further information, please contact our customer service department, c/o Linon Home Décor Products, Inc., between 9:00 AM and 5:00 PM Eastern Standard Time, Monday through Friday:

LINON HOME DÉCOR PRODUCTS, INC.,
CUSTOMER SERVICE DEPARTMENT

- 1) Email address: consumersupport@linon.com
- 2) Toll free number : 1 - 800 - 262 - 1852
- 3) Visit our web site www.Linon.com to order spare parts and for care instructions on your newly purchased furniture.