Assembly Instructions

Caution: You must read this before you proceed

DINING CHAIR



Parts List				
Label	Picture	Description	QTY	
A		Chair Body	1	
В		Leg Frame	1	


Noble house Home Furnishings LLC

Page 1 OF 6

Hardware	<u> </u>		
Label	Picture	Description	QTY
1	0)	Bolt (m6x20mm)	3
2	0)22222	Bolt (m6x16mm)	3
3	0	M6 Flat washer	5
4		M6 Spring washer	5
(5)	©	Aluminum pad	3
6		Allen Key	1

Assembly Preparation

Before Beginning Assembly:





· Read instructions, cover to cover-



Have 2 adults on hand for assembly-



• Do not assemble on flooring or carpet-




Assemble on a clean non-marring surface (packing foam)-




Save all packaging until finished-

Assembly Steps




This Dining Chair has multiple parts and may require up to 30 minutes to assemble. To give you an overview of the Dining Chair parts, the above picture is to help you put the various parts into perspective. Please read through the instructions below to familiarise yourself with the parts and steps before assembly.






Carefully place the Chair Body (B) upside down on a clean, non-marring table. With assistant from second adult, gently place the Leg Frame(B) onto the Chair Body(A) and align the four mounting positions of both, the Leg Frame(B) onto the Chair Body(A).



Attach the front two mounting positions on Leg Frame(B) to the mounting position on Frame (A) using Blot (①), Spring washer (④), Flat washer (③), Aluminum pad (⑤), then tight them by Allen Key (⑥).

Do not fully tighten the Bolts.



Attach the back two mounting positions on Leg Frame(B) to the mounting position on Frame (A) using Blot (②) and Spring washer (④), Flat washer (③), then tight them by Allen Key (⑥).

Do not fully tighten the Bolts.

Step 3



Stand the Chair up and place on flat, level surface.

Carefully and gently sit onto the Chair.

This will help properly align all parts at all joints and remove any gaps.

Carefully get off the Chair and gently turn it over.

Tighen all Bolts at all joints.

When tightening the Bolts, tighten sequentially.


Do not tighten any Bolt fully and then move on towards the next one, this could cause the frame to warp.

If the Chair is not Stable it could lead to damage to the product.

Your Dining Chair is ready for use.

This Dining Chair can only be used on a flat, level surface.

Care & Maintenance



Do not clean furniture with harsh cleansers or polish.

Do not place furniture under direct sunlight.

Do not place furniture near heating or cooling vents.

Do not write on furniture without a padded barrier to protect the surface.

Do not place furniture outside . For indoor use only .

Not for commercial use. For residential use only .

Stains may be removed with mild soap solution and damp cloth.

Children should not climb or jump on the furniture.

Dust and pick-up spills using a clean, non-colored, lint-free cloth .

What is Proposition 65?

Proposition 65 is a California law that requires warning labels on products that may contain one of more than 800-plus chemicals or ingredients that the California Office of Environmental Health Hazard Assessment (OEHHA) has deemed to cause cancer or other reproductive toxicity. Chemicals and elements on this list include wood dust, brass, and other everyday substances, which can be found in very common household items, such as: lamps, tableware, jewelry, crystal glasses, electric cords, beauty products, automobiles, and furniture.

Why Did I Find a Proposition 65 Warning on My Home Goods Product?

We include Proposition 65 warnings on all of our products because there is always a chance that one of the 800-plus common chemicals and ingredients listed under this law could potentially be on our furniture or packing materials. We risk large fines under this law, if we don't include this warning.

Should I worry?

We realize you may be worried finding this warning on our products, but we want to reassure you that the hazardous exposure limits for any of these chemicals have never been found on furniture products that we've shipped to our customers. Additionally, this warning label is very common and can be found on almost every piece of furniture sold in the state of California.

Just How Common Are Proposition 65 Warnings?

Proposition 65 warnings have become so common in California that it is hard to take a trip to a local bank, grocery store, or restaurant without finding at least one warning. In fact, even the Disney Land Resort has a Proposition 65 warning:

