

CARE AND MAINTENANCE

Store outdoor furniture indoors or cover well when not in use.







Remove wooden furniture from standing water. Dust regularly with small brush or vacuum

Spills should be taken care of immediately before they harden or stain with a slightly dampened sponge.

NOTICE

- * Please make sure that you have all parts indicated before you begin assembly of this item
- * This item should be assembled on a soft surface to prevent scratching the finish during assembly
- * This item may require periodic tightening


Part List and Hardware List

PIECE	DESCRIPTION	PICTURE	QUANTITY
A	Frame on table		1X
B	Frame leg		2X
C	Cross bar of leg		1X
H1	Screw -1	 M7x90	4X
H2	Screw -2	 M6x30	8X
H1	Allen key		1X

 **SAFAVIEH**
O U T D O O R

Model# FOX6007A

Product Dimensions:23,62" W x 39,37" D x 17,72" H




PREPARATION

Before beginning assembly of product, make sure all parts are present. Compare parts with package contents list and hardware contents list. If any part is missing or damaged, do not attempt to assemble the product.

Estimated Assembly Time: 10 minutes.

Tools Required for Assembly (included): Allen Key


1



Step 1

Attach front leg (B) to bar (A), using Allen bolt (D), tighten with allen key (H)


2



Step 2

Using Allen bolt (E) to attach to Table top then tighten by allen key (H)

3



Step 3

Attach bar © to leg (B), using Allen bolt (E) to tighten by allen key (H)