

CARE AND MAINTENANCE

Always use felt pads under all articles to prevent discoloration or softening of the lacquer. Plastic and rubber bases on items can discolor wood. Wipe up spills immediately and avoid common hazards such as hot dishes, harsh solvents and abrasives. Cleaning should be done with a soft lint free cotton cloth dampened with water or furniture polish. On highly used surfaces we recommend applying a quality paste wax which should be used on a regular basis to provide additional protection from scratches and spills. How often you apply the wax depends on how much wear the furniture receives.

NOTICE


- * Please make sure that you have all parts indicated before you begin assembly of this item
- * This item should be assembled on a soft surface to prevent scratching the finish during assembly
- * This item may require periodic tightening




Model# FOX2203A

Product Dimensions: 47.2"W×21.6"D×31.1"H

Part List and Hardware List



HW1x13 	HW2x1 	HW3x15 	HW4x15 	HW5x10 	HW6x8 	HW7x2 
HW8x2 	HW9x2  6x35mm	HW10x8  6x30mm	HW11x20  6x12mm	HW12x4  3.5x35mm	HW13x8  4x14mm	




PREPARATION

Before beginning assembly of product, make sure all parts are present. Compare parts with package contents list and hardware contents list.


If any part is missing or damaged, do not attempt to assemble the product.

Estimated Assembly Time: 60 minutes.


1




2




3




4




5




6




7




8



9




10




X2



11




12




13



14



15



16

