




SCAN QR CODE FOR ASSEMBLY VIDEO

Please read below before assembly


- Assemble the product on a flat, soft surface such as a carpet or cloth to prevent scratching the finish.
- Do not discard any content until assembly is complete to avoid accidentally discarding small parts or hardware.
- Take out all parts and hardware from box.
- Failure to follow these instructions may cause the bolts to misalign during assembly.

DISCLAIMERS:

- WHEN PROPERLY ASSEMBLED, THIS ITEM IS SAFE FOR INTENDED USE. SELLER IS NOT LIABLE FOR ANY DAMAGES RESULTING FROM ITEM BEING IMPROPERLY ASSEMBLED AFTER PURCHASE.
- BOLTS MAY LOOSEN DURING NORMAL EVERYDAY USE. THEY SHOULD BE INSPECTED AT LEAST EVERY 3 MONTHS AND RE-TIGHTENED AS NEEDED TO PREVENT DAMAGE OR INJURY, AND ENSURE STABILITY.




TOOLS REQUIRED (NOT INCLUDED)



PARTS LIST

1	HEADBOARD PANEL	1 PC
2	HEADBOARD FINAL	2 PCS
3	RIGHT HEADBOARD LEG	1 PC
4	LEFT HEADBOARD LEG	1 PC
5	HEADBOARD STRETCHER	1 PC
6	SIDE RAIL	2 PCS
7	FOOTBOARD	1 PC
8	FOOTBOARD POST	2 PCS
9	FOOTBOARD DECORATIVE RAIL COMMUNICATION COMU	1 PC
10	FOOTBOARD FINAL	2 PCS
11	MIDDLE SUPPORT	2 PCS
12	SUPPORT LEG \Longrightarrow	10 PCS
13	SLAT ROLL	2 SETS

PARTS LIST



HARDWARE LIST


Α	LARGE BOLT - Ø5/16" x 1-1/2"		10 PCS
В	LARGE LOCK WASHER - Ø5/16"		10 PCS
С	LARGE FLAT WASHER - Ø5/16"	0	10 PCS
D	SMALL BOLT - Ø1/4" x 1-1/4"		8 PCS
Е	SMALL LOCK WASHER - Ø1/4"		8 PCS
F	SMALL FLAT WASHER - Ø1/4"	0	8 PCS
G	STUD BOLT - Ø5/16" x 3-5/8"		8 PCS
Н	CRESCENT WASHER - Ø5/16"	②	8 PCS
I	HEXAGON NUT - Ø5/16"	©	8 PCS
J	SCREW - Ø1/8" x 1-1/4"	A 1111111111	8 PCS
K	ALLEN KEY		1 PC
L	WRENCH - 5/16"		1 PC

STEP 1 LOCATE PARTS AND HARDWARE PER BELOW DRAWING


CARTON A - PART INSIDE : 1,2,3,4,5


CARTON B - PART INSIDE : 7,8,9,10,12,13


CARTON C - PART INSIDE : 6,11





Α	9))))))))	2 PCS	
В		2 PCS	
С	0	2 PCS	
K		1 PC	
			K ABC
	3		(5)

























D	9	4 PCS
Е		4 PCS
F	0	4 PCS
K		1 PC





STEP 15


D	9	4 PCS
Е		4 PCS
F	0	4 PCS
K		1 PC



FOR UNEVEN FLOOR







Care & Maintenance

Do...



Wipe up spills immediately.



Dust and pick-up spills using a clean, non-colored, lint-free, dry cloth.



Use mild non-abrasive soap and water.

Don't...



Do not put hot items directly on furniture surface.



Do not clean furniture with harsh cleansers or polish.



Do not place furniture in direct sunlight.



Do not place furniture near heating or cooling vents.



Do not write on furniture without a padded barrier to protect the surface.



Do not place furniture outside. For indoor use only.