














Signature
MADISON PARK MARINE WOOD FRAME (NON-TEAK) UPHOLSTERED DINING CHAIR (SET OF 2)

Assembly instructions:

PARTS LIST

No.	DESCRIPTION	IMAGE	Q'TY
P1	CHAIR BACK		1
P2	SEAT FRAME		1
P3	FRONT LEG (LEFT)		1
P4	FRONT LEG (RIGHT)		1

HARDWARE LIST

No.	DESCRIPTION	IMAGE	Q'TY
H1	Bolt Ø5/16" x 3"		4
H2	Bolt Ø1/4" x 1-3/4"		1
H3	Lock Washers Ø1/4"		1
H4	Flat Washers Ø1/4"		1
H5	Allen Key		1
H6	Hex Nut Ø5/16"		4
H7	Lock Washers Ø5/16"		8
H8	Flat Washers Ø5/16"		8
H9	Wrench		1

NOTE: PO# is located underneath/ at the back side of each item. Please be prepared to provide this # should any claim be necessary

CAUTION: Item is heavy assembly should be performed by two people.

DISCLAIMER:

When properly assembled, this item is safe for intended use. Seller is not liable for any damages resulting from item being improperly assembled after purchase.

ADDITIONAL NOTE ABOUT SAFETY:

BOLTS MAY LOOSEN DURING NORMAL EVERYDAY USE.

THEY SHOULD BE INSPECTED AT LEAST EVERY 3 MONTHS AND RE-TIGHTENED AS NEEDED TO PREVENT DAMAGE OR INJURY, AND ENSURE STABILITY.

