





# Assembly Instructions

Caution :You must read this before you proceed


## CHARLES CHAIR



## Parts List



Label	Picture	Description	QTY
A		Chair Base	1
B		Front Leg Labeled "B"	2
C		Back Leg Labeled "C"	2

## Hardware

Label	Picture	Description	QTY
①		Washer Ring	7

## Assembly Preparation

Before Beginning Assembly:



- Read instructions, cover to cover-



- Have 2 adults on hand for assembly-



- Do not assemble on flooring or carpet-




- Assemble on a clean non-marring surface (packing foam)-




- Save all packaging until finished-

## Assembly Steps




This CHARLES CHAIR has multiple parts and may require up to some 30 minutes to assemble. To give you an overview of the CHARLES CHAIR parts, the above picture is to help you put the various parts into perspective. Please read through the instructions below to familiarise yourself with the parts and steps before assembly.

### Step 1



Position the Chair Base(A) on its back, as shown.  
Unzip to open pouch and remove the 4 wooden legs and hardware, close the pouch.


## Step 2



Install the Leg(B&C) into the bottom of the Chair Base(A) by placing the Washer Ring(①) onto the threaded stem.  
And then insert the threaded Stem into the threaded Mounting Position at each Corner of the Bottom of the Chair.  
Tighten by turning the Legs clockwise.  
Repeat the same steps to install the three remaining legs.


**Note:**The use of Washer Rings are OPTIONAL and is especially useful to help alleviate slight wobbleness. Some legs may need more than one Washer Rings(①) whilst some legs may not need any.

## Step 3



Place the chair on a LEVEL SURFACE to see if it wobbles.  
If it wobbles, press firmly down on both armrests at the same time. This will help to ensure all Bolts and gaps reach full alignment status.  
If no wobbles found, proceed to tighten all the Bolts. DO NOT fully tighten a BOLT in one go and then move on to the next. Rather, in a sequential manner, gradually tighten each Bolt until all Bolts are evenly secured. This methodology will ensure maximum evenness once all Bolts are fully tightened.

#### Step 4



Your CHARLES CHAIR is ready for use.  
Your CHARLES CHAIR can only be used on a flat, level surface.

## Care & Maintenance



- Furniture may scratch floors. We recommend using furniture pads to protect your floors.



- Do not put hot items directly on furniture surface.



- Do not clean furniture with harsh cleansers or polish.



- Do not place furniture under direct sunlight.



- Do not place furniture near heating or cooling vents.



- Do not write on furniture without a padded barrier to protect the surface.



- Do not place furniture outside . For indoor use only.



- Not for commercial use. For residential use only.



- Stains may be removed with mild soap solution and damp cloth.



- Children should not climb or jump on the furniture.



- Dust and pick-up spills using a clean, non-colored, lint-free cloth.