





Assembly Instructions

CAUTION : You must read this before you proceed







CHAISE LOUNGE



Parts List


Label	Picture	Description	QTY
A		Backrest	1
B		Seat	1
C		Wooden Leg	4

Hardware

Label	Picture	Description	QTY
①		Bolt(M8*70MM)	5
②		Flat Washer Ring	5
③		Spring Washer Ring	5
④		Allen Key	1
⑤		Plastic Washer Ring	7
⑥		Rubber Washer Ring	4

Assembly Preparation

Before
Beginning
Assembly:



• Read instructions, cover to cover-



• Have 2 adults on hand for assembly-



• Do not assemble on flooring or carpet-




• Assemble on a clean non-marring surface (packing foam)-



• Save all packaging until finished-


Assembly Steps

OVERVIEW




This Chaise Lounge has multiple parts and may require up to 20 minutes to assemble. To give you an overview of the Chaise Lounge parts, the above picture is to help you put the various parts into perspective. Please read through the instructions herebelow to familiarise the parts and steps before assembly.

Step 1




Position the Seat(B) on its side, as shown. (Preferably on a surface that won't scratch the upholstery). Remove the non-woven fabric from under the Seat(B) and take out the 4pcs Wooden Legs(B), and hardware package.

Step 2




Attach the Backrest(A) to the Seat(B) use Bolt(①), Flat Washer Ring(②), Spring Washer Ring(③) with Allen Key(④). Then close the non-woven fabric.

Step 3

































Install the Wooden Leg(C) onto the Seat(B) by putting a Plastic Washer Ring(⑤)(optional but improves security and tightness), a Rubber Washer Ring(⑥) onto the threaded stem. Insert the threaded stem into the threaded hole at each corner of the bottom of the Seat(B). Tighten the leg by turning clockwise. Repeat the same steps to install the remaining three legs.

Step 4



Turn the Chaise Lounge to its upright position. It is now ready for use.

Care & Maintenance

- 

 Do not put hot items directly on furniture surface
 - 

 Do not clean furniture with harsh cleansers or polish.
 - 

 Do not place furniture under direct sunlight.
 - 

 Do not place furniture near heating or cooling vents.
 - 

 Do not write on furniture without a padded barrier to protect the surface.
 - 

 Do not place furniture outside . For indoor use only .
 - 

 Not for commercial use. For residential use only .
 - 

 Stains may be removed with mild soap solution and damp cloth.
 - 

 Children should not climb or jump on the furniture.
-
- 

 Dust and pick-up spills using a clean, non-colored, lint-free cloth .