


Assembly Instructions



COFFEE TABLE

CAUTION: You must read this before you proceed.






CAUTION : This Coffee Table is NOT a TOY.
Keep your child / children at bay in the process of assembly.
For turning the Coffee Table and to prevent damage to the Coffee Table,
02 persons may be needed to execute this action.

Parts List

No.	Picture	Description	Qty
A		Table Top	1
B		Legs	3


Hardware

Table Hardware

No.	Picture	Description	Qty
①		Bolts M8x55mm	7
②		Flat Washers M8	7
③		Allen Key	1

Assembly Preparation

Before Beginning Assembly:



☒ Read instructions, cover to cover.



☒ Have 2 adults on hand for assembly.



☒ Do not assemble on flooring or carpet.




☒ Assemble on a clean non-marring surface (packing foam).



☒ Save all packaging until finished.


Assembly Steps

OVERVIEW



This Coffee Table has multiple parts and may require up to 30 minutes to assemble. To give you an overview of the Coffee Table parts, the above picture is to help you put the various parts into perspective. Please read through the instructions herebelow to familiarise the parts and steps before assembly.


Step 1



Unpack and place all parts on a clean, non-marring surface.

Assembly Steps

Step 2




Place the Table Top (A), top facing down, onto a clean, soft surface that will not scratch or damage the table top.

Pick up one leg (B) and align to the housing at the edge-corner of the table apron. Each leg is to be mounted with two Bolts (①) and Flat Washers (②), by using the Allen Key (③).

**Repeat the same process with the remaining 2 legs.
DO NOT FULLY TIGHTEN BOLTS.**

Assembly Steps


Step 3



Turn the Coffee Table right side up.
Inspect it and make sure all parts are adequately connected.
Ensure there is no wobbles.
In a sequential manner, ensure all bolts are fully locked into position and secured.





















CAUTION : When tightening these bolts, tighten sequentially.
DO NOT tighten any screw fully and then towards the next one. This would cause the frame to warp.
If there is still wobbles, loosen the bolts and execute this same drop tests.
WARNING!! IF TABLE IS NOT STABLE , IT COULD LEAD TO DAMAGING THE PRODUCT.

Step 4



Ensure all bolts are fully locked into position.
The Coffee Table is ready to be used.
Caution: This Coffee Table can only be used on a flat, level surface.

Care & Maintenance

-   Do not put hot items directly on furniture surface.
-   Do not clean furniture with harsh cleansers or polish.
-   Do not place furniture under direct sunlight.
-   Do not place furniture near heating or cooling vents.
-   Do not write on furniture without a padded barrier to protect the surface.
-   Do not place furniture outside. For indoor use only.
-   Not for commercial use. For residential use only.
-   Stains may be removed with mild soap solution and damp cloth.
-   Children should not climb or jump on the furniture.
-   Dust and pick-up spills using a clean, non-colored, lint-free cloth.