


Operating Instructions

Caution : You must read this before you proceed


CHAIR



CAUTION : This Chair is NOT a TOY.
Keep your child / children at bay when opening or folding the Chair.

Operating Instructions

Step 1




Position the Chair as pictured.

To open, open magic tape tape as shown above.

Then unfold Frame as indicated by the arrows, by hand, until the Chair fully folds out.

Step 2




Turn back the pillow onto the canvas seat as above picture.

Your Chair is ready for use.


This Chair can only be used on a flat, level surface.

Step 3












To close, fold Leg Frame as indicated by the arrows, by hand, until the Chair folds shut.

Step 4



Note: There is a magic tape straps beside Leg Frame, tie the magic tape straps to Leg Panel as picture shown.

Care & Maintenance

- ⊘  ● Do not put hot items directly on furniture surface.
 - ⊘  ● Do not clean furniture with harsh cleansers or polish.
 - ✓  ● To obtain the longest lifespan of your outdoor products, minimizing exposure to direct sunlight is recommended.
 - ⊘  ● Children should not climb or jump on the furniture.
 - ⊘  ● Do not write on furniture without a padded barrier to protect the surface.
 - ✓  ● To obtain the longest lifespan of your outdoor products, avoid extended and lengthy exposure to rain, snow, and direct sunshine. Whenever possible cover the product and /or place under patio or awnings.
 - ⊘  ● Not for commercial use. For residential use only.
 - ⊘  ● Stains may be removed with mild soap solution and damp cloth.
 - ✓  ● Dust and pick-up spills using a clean, non-colored, lint-free cloth .
-