# **Assembly Instructions**

Caution: You must read this before you proceed.

# **SUPPORT STAND**



CAUTION: Do Not Swing on or in chair. This could cause the product to tip over resulting in possible injury.

This Support Stand is NOT a TOY.


Keep your child / children at bay during the assembly process.

Parts List					
No.	Picture	Description	Qty		
A	Out of the control of	Base Loosely (Pre- attached with Part F)	1		
В		Base Booms - Curved	2		
С	0	Base Straight Boom Loosely	1		
D		Bent Metal Holder	1		
E	•	Straight Metal Holder	1		
F		Safety Strip	1		

Hardware					
1	<b>Campu</b>	Nut M8*25	2		
2		Nut M8*16	6		
3		Bolt and Nut M8*45	2		
4		Bolt and Nut M10*65	2		
(5)		Wrench (M8)	2		
6		Wrench (M10)	2		

# Assembly preparation

# Before Beginning Assembly:





• Read instructions, cover to cover-



Have 2 adults on hand for assembly-




Do not assemble on flooring or carpet-




Assemble on a clean non-marring surface (packing foam)-



Save all packaging until finished-




This Stand has multiple parts and may require up to 20 minutes to assemble. To give you an overview of the Table parts, the above picture is to help you put the various parts into perspective. Please read through the instructions below to familiarise yourself with the parts and steps before assembly.



Open the carton and place all the parts on a clean, non-marring surface.


# Step 2



Attached Base Straight Boom Loosely ( C ) to Base Loosely (Pre-attached with Part L) (A)

Attention: Should Push C to the end of bottom of A

## Step 3




Step 3.1: Attached Base Booms - Curved (B) to Base Loosely (Pre-attached with Part ①) - (A) Using Nuts (②) with Wrench (⑤).

PS: B have B1 and B2, There is a label in products, pls pay attention: B1 to B1, B2 to B2. Don't Fully tighten the nuts in this step.


# Step 4.1 B2 Step 4.2 Step 4.2 B2 C B2

Repeat Step 3.

PS: B have B1 and B2, There is a label in products, pls pay attention: B1 to B1, B2 to B2. Don't Fully tighten the nuts in this step.




You should drag out Part (C) a little in this step, then attached Base Straight Boom Loosely (C) to Base Booms - Curved (B) using Wrench ( $\mathfrak{S}$ ) with Nuts set ( $\mathfrak{S}$ ). Fully tighten all nuts.




Attached Straight Metal Holder ( E ) to Base Loosely (A) (Pre-attached with Part (1) using Wrench (6) with Nuts set (4).

PS: You should loosen nut using Wrench(⑥) before this step.




Attached Bent Metal Holder (D) to Straight Metal Holder (E) using Wrench (⑤) with Nut (②).


PS: Fully tighten nuts.



The stand are ready to use.



You should to fasten the safety strip (F) before using .



## Care & Maintenance



Do not put hot items directly on furniture surface



- Do not clean furniture with harsh cleansers or polish.
- ✓ Ö:
- To obtain the longest lifespan of your outdoor prodcts, minimizing exposure to direct sunlight is recommended.
- o 🟋
- Children should not climb or jump on the furniture.
- Do not write on furniture without a padded barrier to protect the surface.



- To obtain the longest lifespan of your outdoor products, avoid extended and lengthy exposure to rain, snow, and direct sunshine. Whenever possible cover the product and /or place under patio or awnings.
- 0
- Not for commercial use. For residential use only.
- 0
- Stains may be removed with mild soap solution and damp cloth.



Keep away from sources of ignition.



Dust and pick-up spills using a clean, non-colored, lint-free cloth .

## What is Proposition 65?

Proposition 65 is a California law that requires warning labels on products that may contain one of more than 800-plus chemicals or ingredients that the California Office of Environmental Health Hazard Assessment (OEHHA) has deemed to cause cancer or other reproductive toxicity. Chemicals and elements on this list include wood dust, brass, and other everyday substances, which can be found in very common household items, such as: lamps, tableware, jewelry, crystal glasses, electric cords, beauty products, automobiles, and furniture.

## Why Did I Find a Proposition 65 Warning on My Home Goods Product?

We include Proposition 65 warnings on all of our products because there is always a chance that one of the 800-plus common chemicals and ingredients listed under this law could potentially be on our furniture or packing materials. We risk large fines under this law, if we don't include this warning.

### Should I worry?

We realize you may be worried finding this warning on our products, but we want to reassure you that the hazardous exposure limits for any of these chemicals have never been found on furniture products that we've shipped to our customers. Additionally, this warning label is very common and can be found on almost every piece of furniture sold in the state of California.

## Just How Common Are Proposition 65 Warnings?

Proposition 65 warnings have become so common in California that it is hard to take a trip to a local bank, grocery store, or restaurant without finding at least one warning. In fact, even the Disney Land Resort has a Proposition 65 warning:

