

CARE AND MAINTENANCE

Unplug lamps before using any cleaning solutions. Dust shades with a feather duster or with an appropriate vacuum-brush attachment. Wipe with a soft, dry cloth and clean lamp bases with the methods appropriate to the material. Avoid the use of chemicals and household cleaners as they may damage the finish.



NOTICE & IMPORTANT SAFETY INSTRUCTIONS









- * Please make sure that you have all parts indicated before you begin assembly of this item
- * This item should be assembled on a soft surface to prevent scratching the finish during assembly
- * To reduce the risk of fire, electrical shock or injury to persons or property, please follow the guideline below for safe use and installation
- *The external flexible cable or cord of this luminaire cannot be replaced;
If the cord is damaged, the luminaire shall be destroyed


Model# LIT4483A

Product Dimensions: Ø11.8" X 59.5"H

**This portable lamp has a polarized plug (one blade is wider than the other) as a safety feature to reduce the risk of electric shock. this plug will fit in a polarized outlet only one way. if the plug does not fit fully in the outlet, reverse the plug, if it still does not fit, contact a qualified electrician. never use with an extension cord unless the plug can be fully inserted. do not attempt to defeat this safety feature.

Part List and Hardware List

PIECE	DESCRIPTION	PICTURE	QUANTITY	PIECE	DESCRIPTION	PICTURE	QUANTITY
A	Finial		1X	E	Bottom Tube		1X
B	Shade Spider		1X	F	Base		1X
C	Top Tube		1X	G	Bulb		3X
D	Lampbody		1X	H	Capiz Strand		27X





PREPARATION

Before beginning assembly of product, make sure all parts are present. Compare parts with package contents list and hardware contents list. If any part is missing or damaged, do not attempt to assemble the product.
Estimated Assembly Time: 6 minutes.


CAUTION: Cut the "H" plastic buckles with scissor when take down the PE bags

**PLEASE USE ON/OFF TYPE "B" BULB MAX 40-WATT OR CFL BULB MAX 9-WATT
THERE ARE 3PCS TYPE "B" BULBS 25-WATT IN THE BOX**




Step 1

Make sure all parts could be aligned before assemble
Do not rotate lamp body too hard avoid base screw broken
Screw the Bottom Tube (E) into the Base (F)
Screw the Lampbody (D) into the Bottom Tube (E)
Screw the Top Tube (C) into the Lampbase (D)
Be careful not to twist the power cord and tighten securely



Step2

Insert the Shade Spider(B) into the threaded portion of the Top Tube(C) and fix it by turning the Finial(A) clockwise.



Step3

Insert the hook of each Capiz Strand(H) into the hole of the Shade Spider(B) as diagram.
Insert the Bulb(G) into the socket.

ENJOY YOUR LAMP