





Assembly Instructions

Caution :You must read this before you proceed


Club Chair



Parts List



| Label | Picture | Description | QTY |
|-------|---|-------------|-----|
| A |  | Chair Base | 1 |
| B |  | Front Leg | 2 |
| C |  | Back Leg | 2 |

Hardware

| Label | Picture | Description | QTY |
|-------|---|-------------|-----|
| ① |  | Washer Ring | 7 |

Assembly Preparation

Before Beginning Assembly:



- Read instructions, cover to cover-



- Have 2 adults on hand for assembly-



- Do not assemble on flooring or carpet-




- Assemble on a clean non-marring surface (packing foam)-




- Save all packaging until finished-


Assembly Steps




This Club Chair has multiple parts and may require up to some 30 minutes to assemble. To give you an overview of the Club Chair parts, the above picture is to help you put the various parts into perspective. Please read through the instructions below to familiarise yourself with the parts and steps before assembly.



Position the chair on its back, as shown.
 Unzip to open pouch and remove the 4 wooden legs, close the pouch.



Put the chair onto a flat table as shown in pix.
 Insert the Front Leg(B) into the mounting position of Chair Base(A).
 Attach the Front Leg(B) using Washer Ring(①).
 Repeat the same process to install the remaining three Legs.
 Tighten by turning the Leg clockwise.
 Note: The use of Washer Rings(①) are OPTIONAL and are especially useful to help alleviate slight wobbles. Some Legs may need more than one Washer Ring whilst some Legs may not need any.



Stand the Club Chair right side up.
 Your Club Chair is ready for use.
 Your Club Chair can only be used on a flat, level surface.

Care & Maintenance



- Furniture may scratch floors. We recommend using furniture pads to protect your floors.



- Do not put hot items directly on furniture surface.



- Do not clean furniture with harsh cleansers or polish.



- Do not place furniture under direct sunlight.



- Do not place furniture near heating or cooling vents.



- Do not write on furniture without a padded barrier to protect the surface.



- Do not place furniture outside . For indoor use only.



- Not for commercial use. For residential use only.



- Stains may be removed with mild soap solution and damp cloth.



- Children should not climb or jump on the furniture.



- Dust and pick-up spills using a clean, non-colored, lint-free cloth.