




# Assembly Instructions

**Caution : You must read this before you proceed**




## Dining Chair



### Parts List



Label	Picture	Description	QTY
A		Chair Body	1
B		Front Leg(with Pre-installed Levellers )	2
C		Back Leg(with Pre-installed Levellers )	2

## Hardware

Label	Picture	Description	QTY
①		Bolt (M6 x 12mm)	13
②		Allen Key	1
③		Spare Leveller	2

## Assembly Preparation

Before  
Beginning  
Assembly:



- Read instructions, cover to cover-



- Have 2 adults on hand for assembly-



- Do not assemble on flooring or carpet-




- Assemble on a clean non-marring surface (packing foam)-



- Save all packaging until finished-


# Assembly Steps

## Overview



This Dining Chair has multiple parts and may require up to 30 minutes to assemble. To give you an overview of the Dining Chair parts, the above picture is to help you put the various parts into perspective. Please read through the instructions below to familiarise yourself with the parts and steps before assembly.

## Step 1




Place the Chair Body(A) facedown on the edge of a clean, non-marring Table Top.

Attach Front Legs(B) to Chair Body(A) using Bolts(①) with Allen Key(②) as pictured above.

**Tightening all Bolts completely in a sequential manner.**



## Step 2



Attach Back Legs(C) to Chair Body(A) using Bolts(①) with Allen Key(②) as pictured above.

**Tightening all Bolts completely in a sequential manner.**

## Step 3



**Adjust Pre-installed  
Levellers height for balance**

Stand the Chair up and place on flat, level surface.



















If the Chair wobbles adjust the Pre-installed Levellers at the bottom of the Legs until the Chair is level.



Your Chair is ready for use.

Note: 2pcs Spare Levellers can be used if any of them damaged.

**This Chair can only be used on a flat, level surface.**

## Care & Maintenance

-   • Do not put hot items directly on furniture surface
-   • Do not clean furniture with harsh cleansers or polish.
-   • Do not place furniture under direct sunlight.
-   • Do not place furniture near heating or cooling vents.
-   • Do not write on furniture without a padded barrier to protect the surface.
-   • Do not place furniture outside . For indoor use only .
-   • Not for commercial use. For residential use only .
-   • Stains may be removed with mild soap solution and damp cloth.
-   • Children should not climb or jump on the furniture.

- 
-   • Dust and pick-up spills using a clean, non-colored, lint-free cloth .