




Assembly Instructions

Stool Chair





Caution : You must read this before you proceed.



Parts List






Label	Picture	Description	Qty
A		Seat	1
B		Leg	4

Hardware

Label	Picture	Description	Qty
C		Bolt Dia.M8X50mm (L)	9
D		Dia: 8MM	9
E		Dia: 22MM	9
F		Allen Key	1


Assembly Preparation

Before Beginning Assembly:


-  • Read instructions, cover to cover-
-  • Have 2 adults on hand for assembly-
-  • Do not assemble on flooring or carpet-
-  • Assemble on a clean non-marring surface (packing foam)-
-  • Save all packaging until finished-

Assembly Steps

Parts Introduction



Step 1




Position the Chair on its reverse side, as shown in above picture, preferably on a surface that will not scratch the upholstery.

Remove the non-woven bottom cover.

Take out 04 pcs of Wooden Legs and a bag of hardware (9 bolts and 1 Allen key).

Step 2



Install the legs on the leg position located on the underside of the Bench.

Make sure the 'overhang' on the Leg Frame is facing outwards.

Slide-insert the grooves of the Wooden Legs into the tenons on the Bench.

Insert one Spring Washer Ring (D) and then one Flat Washer Ring (E) into each Bolt(C)

Insert the Bolt through the mounting position on the corner of the Bench into the threaded mounting position in leg.


Use the Allen Key(F) to tighten the Bolts, by turning clockwise.

Each leg shall be bolted down with 02 Bolts.

DO NOT overtighten the first time around for all Bolts.

Repeat the same steps to install the remaining 3 legs.

Step3



Place the chair on a LEVEL SURFACE to see if it wobbles.

If it wobbles, lift the chair to some 30cm to 50cm height from the ground.

Keep your feet and toes well away from the drop zone.

Drop the chair freely and vertically with the four legs, hitting the ground, at the same time.

This Drop Test will help to ensure that all the bolts and gaps to all reach full alignment status.

Test again for evenness on a LEVEL SURFACE.

If no wobbles found, proceed to tighten all the bolts.

CAUTION : When tightening these bolts, tighten sequentially.


DO NOT tighten any screw fully and then towards the next one.

This would cause the frame to warp.

If there is still wobbles, loosen the bolts and execute this same drop tests.

WARNING!! IF CHAIR IS NOT STABLE , IT COULD LEAD TO DAMAGING THE PRODUCT.

Step4



Once all legs are affixed, fully tighten all 8 bolts on all 4 legs, in a sequential manner.

Inspect and make sure all parts are connected, locked and fully secured into position.

Seal the non-woven bottom cover back to the underside of the Bench.

Turn it right side up.

The Bench is ready to be used.

Care & Maintenance



- Do not put hot items directly on furniture surface



- Do not clean furniture with harsh cleansers or polish.



- Do not place furniture under direct sunlight.



- Do not place furniture near heating or cooling vents.



- Do not write on furniture without a padded barrier to protect the surface.



- Do not place furniture outside . For indoor use only .



- Not for commercial use. For residential use only .



- Stains may be removed with mild soap solution and damp cloth.



- Children should not climb or jump on the furniture.



- Dust and pick-up spills using a clean, non-colored, lint-free cloth .