



Assembly Instructions




Caution : You must read this before you proceed

Glider Reclining Chair





Parts List

Label	Picture	Description	QTY
A		Chair Backrest	1

B		Chair Base with Footrest	1
C		Left Armrest with Zipper (Labelled C)	1
D		Right Armrest with Zipper (Labelled D)	1

Assembly Preparation

Before Beginning Assembly:



- Read instructions, cover to cover-



- Have 2 adults on hand for assembly-



- Do not assemble on flooring or carpet-




- Assemble on a clean non-marring surface (packing foam)-



- Save all packaging until finished-


Assembly Steps

Parts Introduction




This Glider Reclining Chair has multiple parts and may require up to some 30 minutes to assemble. To give you an overview of the Chair parts, the above picture is to help you put the various parts into perspective. Please read through the instructions below to familiarise yourself with the parts and steps before assembly.

Step 1




Take out the Chair Backrest(A) from Chair Base with Footrest(B).

Step 2




Take out 2 non-woven bags with the Armrest with Zipper from the back of Chair Base with Footrest(B).

Step 3



Take out the non-woven bag with the Armrest with Zipper inside from the bottom of Chair Base with Footrest(B).

Step 4




With assistance from your adult partner, hold up the Chair Backrest(A), while standing behind the Chair.

Insert the small metal arms on the sides of the Chair Backrest(A) into the prefabricated slide lock gadget on the Chair Base with Footrest(B) as shown above.


Firmly but gently, push the Chair Backrest(A) downwards until the **Backrest is fully slotted and locked into position.**

Step 5




Attach Right Armrest with Zipper(D) to Chair Base with Footrest(B) using Zipper.

Step 6




Attach Left Armrest with Zipper(C) to Chair Base with Footrest(B) using Zipper.


Step 7



Smooth down the fabric flap on the Chair Backrest(A).
Run your hands down both sides of the flap, from top to bottom, allowing the velcro tape to adhere to the flap under the seat of the chair.



Make sure all parts are connected and securely locked into position.
Your Chair is ready for use.



Disassembly Note:Open the flap on the Chair Backrest(A),use a screwdriver(Don't use fingers) pressing outward on the metal ear on the preattached Metal Bracket on one side of the Chair Base(B),with assistance of you adult partner to keep the Chair Base(B) in place, pull out the Chair Backrest(A) upward at the same time,repeat the same step for another side.Then the Chair Backrest(A) can be taken out.


User Instructions.

Glider Reclining Chair

Please read the Instruction Manual below carefully before use.
--

This is a Glider Recliner Chair. At anytime in a reclined seat position or in the upright position. You may enjoy the rocking motion by using your body weight in a back-front rocking motion.
--

Supervise children, when in use of this Glider Recliner Chair.
--



Do not let children stand in front of or behind the Glider Reclining Chair when opening or closing the footrest.

Do not put you hands inside the Footrest when opening or closing the footrest.

Do not sit any armrest of Chair.


Do not open trigger when you want to close the Footrest, just push it by your feet.

To get into a reclined posture - To Recline backrest

Sit into the seat.

Open the trigger on the outside of right armrest.

Use your body weight and push backwards into the seat into a fully reclined position.



To get out of chair - move Seatback into Upright Position


Tilt your body weight slightly forward and upwards.

The seat back will come up to an upright position.

Use your feet to push the footrest down.

The chair will automatically lock when it is in the fully upright position.

Where necessary, use your arms help lift/push yourself out of the seat.



Care & Maintenance



- Do not put hot items directly on furniture surface



- Do not clean furniture with harsh cleansers or polish.



- Do not place furniture under direct sunlight.



- Do not place furniture near heating or cooling vents.



- Do not write on furniture without a padded barrier to protect the surface.



- Do not place furniture outside . For indoor use only .



- Not for commercial use. For residential use only .



- Stains may be removed with mild soap solution and damp cloth.



- Children should not climb or jump on the furniture.



- Dust and pick-up spills using a clean, non-colored, lint-free cloth .