
Assembly Instructions

CAUTION: You must read this before you proceed

Please look in the iron leg for hardware packs.

TABLE



CAUTION: This Table is NOT a TOY


Keep your child/ children at bay during the assembly process.

For moving the Table and to prevent damage to the Table, two adults are needed to execute this action.

Parts List			
Label	Picture	Description	QTY
А		Table Top	1
В		Iron Leg	2
С		Turnbuckle frame	1
<u>Hardware</u>			
Label	Picture	Description	QTY
1)		Bolt (M8x20mm)	12
2		Washer (M8.5x20x2mm)	12
3		Allen Wrench	1

Assembly Preparation

Before Beginning Assembly:





Read instructions, cover to cover-



Have 2 adults on hand for assembly-



Do not assemble on flooring or carpet-




Assemble on a clean non-marring surface (packing foam)-




Save all packaging until finished-


Assembly Steps



This Table has multiple parts and may require up to some 30 minutes to assemble. To give you an overview of the Table parts, the above picture is to help you put the various parts into perspective. Please read through the instructions below to familiarise yourself with the parts and steps before assembly.



Unpack and place all parts on a clean non -marring surface.




Place the Table top (A) upside down to clean surface to avoid any scratches to product.

Attach the Leg (B) to the Table top (A) as shown in picture above.

Using Bolts (1), Washers (2) and Allen Wrench (3) to secure the Legs (B) with the Table top (A).

Do not fully tighten the bolts.




Attach the Turnbuckle frame (C) into assembled frame as shown in picture above.

- **3.1)** Affix the Turnbuckle frame (C) with the Table top (A) by using Bolts (1), Washer (2) and Allen Wrench (3).
- **3.2)** Affix the Turnbuckle frame (C) with the Legs (B) by using Bolts (1), Washer (2) and Allen Wrench (3) as shown in picture

Do not fully tighten the bolts.

Step 4



Turn the Table right side up.

Place the Table on a LEVEL SURFACE.

Inspect it and make sure all parts are adequately connected.

Gently and gracefully, place a force onto the table top.

This would help to align all the parts at all the joint areas.

Then proceed to tighten all bolts sequentially.

DO NOT tighten any screw fully and then towards the next one.

This would cause the frame to warp.

If there is still wobbles, loosen the screws and execute this same process.

WARNING!! IF THE TABLE IS NOT STABLE, IT COULD LEAD TO DAMAGING THE PRODUCT.

Ensure all bolts are fully locked into position.

Notice: By hand, turn the Turnbuckles to further secure the Table and maximize stability and show the Turnbuckle as place as the picture

Your Table is ready for use

This Table can only be used on a flat, level surface

Care & Maintenance





- Prolonged exposure to rain may cause rusting which can stain floors.
- Ø 💆
- Do not put hot items directly on furniture surface.
- Ø 🖣
- Do not clean furniture with harsh cleansers or polish.
- / Ö
- To obtain the longest lifespan of your outdoor products, minimizing exposure to direct sunlight is recommended.
- ⊘ 🟋 Child
 - Children should not climb or jump on the furniture.
- 0 L
- Do not write on furniture without a padded barrier to protect the surface.
- **√** ○
- To obtain the longest lifespan of your outdoor products, avoid extended and lengthy exposure to rain, snow, and direct sunshine. Whenever possible cover the product and /or place under patio or awnings.
- Not for commercial use. For residential use only.
- Stains may be removed with mild soap solution and damp cloth.
- 10
- Dust and pick-up spills using a clean, non-colored, lintfree cloth.