



## Net Chair

### Assembly Guide



#### Step 1: ASSEMBLING THE NET CHAIR

1. Spread net out on the ground. Make sure that ropes are not twisted, knotted, or overlapped.
2. Feed the two spreader bars through the net loops as well as the rope loops extending from the O-ring.

#### Step 2: HANGING THE NET CHAIR

1. Hang the chair via the the O-ring on your pre-installed hook.

### CAUTION!

**DO NOT JUMP OR BOUNCE IN THE HAMMAKA NET CHAIR; DOING SO MAY CAUSE SERIOUS INJURY OR DEATH!**

The Hammaka Net Chair's maximum weight capacity is 220 lbs. Do not exceed maximum weight capacity. Inspect hooks, and hardware before each use for rust or loosening that makes this product unsafe to use. If the functionality of the hardware has been compromised in any way do not use this product as doing so may cause serious injury or death. It may be necessary to tighten the hardware each time before using this product due to hot or cold weather conditions. Inspect the overall condition of this product before each use. Children should not use the Net Chair without adult supervision. Do not hang your chair more than eighteen inches above the ground. Make sure there are no sharp objects or harmful debris below where you hang your net chair.

#### WARRANTY AND CARE INSTRUCTIONS

##### Two year warranty.

For maximum life of this product Hammaka recommends putting the item indoors when you are located in extreme weather conditions. Check all connections to make sure they are secure each time before and periodically while using the product. Check that the hardware has not rusted. Hammaka recommends using a rust inhibitor available at your local hardware store to prolong the life of the hardware when leaving it outdoors.

Clean with mild soap and warm water, scrubbing when necessary.

Register your warranty online at [www.hammaka.com](http://www.hammaka.com).

Extend the use and life of your Net Chair by purchasing the All-weather Chair Cover from Hammaka.

