

CARE AND MAINTENANCE

Always use felt pads under all articles to prevent discoloration or softening of the lacquer. Plastic and rubber bases on items can discolor wood. Wipe up spills immediately and avoid common hazards such as hot dishes, harsh solvents and abrasives. Cleaning should be done with a soft lint free cotton cloth dampened with water or furniture polish. On highly used surfaces we recommend applying a quality paste wax which should be used on a regular basis to provide additional protection from scratches and spills. How often you apply the wax depends on how much wear the furniture receives.

NOTICE


- * Please make sure that you have all parts indicated before you begin assembly of this item
- * This item should be assembled on a soft surface to prevent scratching the finish during assembly
- * This item may require periodic tightening













Model# FOX2234A

Product Dimensions: 47.2"W×23.6"D×13.4"/22.2"H

Part List and Hardware List



HW1x30 	HW2x30 	HW3x8 	HW4x1 	HW5x1 	HW6x4  6x20mm
HW7x20  6x12mm	HW8x2 	HW9x4 	HW10x1 		





PREPARATION

Before beginning assembly of product, make sure all parts are present. Compare parts with package contents list and hardware contents list.

If any part is missing or damaged, do not attempt to assemble the product.


Estimated Assembly Time: 60 minutes.

1





2



3




4




5




6




7




8




9




10




11




12



13





CAUTION

POSSIBLE FINGER ENTRAPMENT MAY
OCCUR WHEN OPENING AND CLOSING DESK
DRAWER
KEEP FINGERS AWAY FROM MOVING PARTS
NEVER ALLOW A CHILD TO OPEN OR CLOSE
THE DESK DRAWER