


ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

900262 ***Accent Chair W/Ottoman***

REVISION 0 : 11/30/2016
REVISION 1 : 01/03/2019
REVISION 2 : 06/08/2019
REVISION 3 : 09/23/2019
REVISION 4 : 11/08/2022
REVISION 5 : 03/15/2023

ITEM:900262



ASSEMBLY INSTRUCTIONS


ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishment.



ASSEMBLY TIME

20 MINUTES

PARTS IDENTIFICATION

AN SEAT CUSHION



1PC

BN FRONT LEGS



2PCS

CLN LEFT BACK LEG



1PC

CRN RIGHT BACK LEG



1PC

D OTTOMAN CUSHION



1PC

E OTTOMAN LEG



4PCS

ZN HARDWARE IDENTIFICATION


NO	DESCRIPTION	FIGURE	Q' TY
1	ØLOCK WASHER 5/16"		8PCS
2	ØFLAT WASHER 5/16"		8PCS
3	ØBOLT 5/16X2-1/2"		8PCS
4	ØALLEN KEY 5mm		1PC
5	ØSCREW 8X1-3/4"		8PCS

ITEM:900262




ASSEMBLY INSTRUCTIONS


STEP: 1



STEP: 2




STEP: 3



ITEM:900262



ASSEMBLY INSTRUCTIONS



Note: Dimension tolerance $\pm 5\%$