


ASSEMBLY INSTRUCTIONS
COASTER FINE FURNITURE



Fine Furniture for every stage of life

501157
BENCH

REVISION 0 : 09/05/2017
REVISION 1 : 10/06/2023

ITEM:501157

ASSEMBLY INSTRUCTIONS



ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!


1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.

ASSEMBLY TIME 35 MINUTES

PARTS IDENTIFICATION

A


CUSHION



1PC

B


CUSHION FRAME



1PC

C

CROSSBAR



2PCS

D

SIDE




2PCS

Z

HARDWARE IDENTIFICATION

1

SCREW
(8# x 35mm)



6PCS

3

LEVELER
(1/4" x 12mm BLK)



4PCS

2


ALLEN BOLT
(1/4" x 12mm SR)



16PCS

4

ALLEN WRENCH
(4mm)




1PC

ITEM: 501157 ASSEMBLY INSTRUCTIONS




STEP 1


Do not tighten until each step is completed or instructed.




STEP 2



ITEM: 501157
ASSEMBLY INSTRUCTIONS
STEP 3



STEP 4
COMPLETE




ITEM: 501157 ASSEMBLY INSTRUCTIONS



Product Size : 1219 X 406 X 470 H (MM)

Product Size : 48" X 16" X 18 ½"



Note : Dimension tolerance $\pm 5\%$