

ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

100889N Counter Height Chair

REVISION 0: 05/11/2010 REVISION 1: 09/11/2012 REVISION 2: 11/05/2019

COASTERFURNITURE.COM

ITEM: 100889N



ASSEMBLY INSTRUCTIONS

ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME

5 MINUTES

PARTS IDENTIFICATION

1	BACK FRAME	1PC	4L LEFT FRONT LEG	•	1PC
2	SEAT CUSHION WITH FRAME	1PC	4R RIGHT FRONT LEG	·	1PC
3L	LEFT SIDE STRETCHER	1PC	5 FRONT STRETCHER		1PC
3R	RIGHT SIDE STRETCHER	1PC			

HARDWARE IDENTIFICATION

Α	LONG BOLT (Ø1/4" x 3" - RBW)	4PCS	E	FLAT WASHER (Ø5/16" - RBW)		9PCS
В	MEDIUM BOLT (Ø1/4" x 2-3/8" - RBW)	4PCS	F	FLAT HEAD SCREW (Ø4 x 40mm - RBW)	(†)	6PCS
С	SHORT BOLT (Ø1/4" x 1-3/8" - RBW)	1PC	G	ALLEN WRENCH (M4 x 59mm - RBW)		1PC
D	LOCK WASHER (Ø5/16" - RBW)	9PCS				

NOTE:

Quantities shown are for one chair.


Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.

ITEM: 100889N


COASTER

ASSEMBLY INSTRUCTIONS


STEP 1




STEP 2



STEP 3




STEP 4 COMPLETE



PAGE 3 OF 3

ITEM: 100889N





Note: Dimension tolerance ±5%