















ITEM # 139-B100024 DESCRIPTION WINDSOR BARSTOOL

Thank you for purchasing this quality product. Be sure to check all packing material carefully for small parts which may have some loose inside the carton during shipment. Identify and count all parts and compare with the parts List Below :




PARTS LIST

SKETCH							
DESCRIPTION	Hoop	Seat Board	Spindle	Front Leg (R)	Front Leg (L)	Back Leg (R)	Back Leg (L)


SKETCH						
DESCRIPTION	Lower Side Stretcher	Upper Side Stretcher	Lower Front Stretcher	Upper Front Stretcher	Lower Back Stretcher	Upper Back Stretcher

ASSEMBLY STEP


STEP 1




STEP 2




STEP 3



STEP 4



STEP 5



STEP 6

Turn the chair upright. Check it balance.

