

# ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

### 120341 BARSTOOL

REIVSION 0:06/16/2020 REIVSION 1:08/04/2022 REIVSION 2:09/01/2023

## ITEM:120341 ASSEMBLY INSTRUCTIONS



#### **ASSEMBLY TIPS:**

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



Warning!

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.





ASSEMBLY TIME 5 MINUTES

#### PARTS IDENTIFICATION


	PART NAME	FIGURE	QTY
A	TABLE BASE	0	1PC
В	TABLE TOP	-600mm-	1PC
C	MAIN POST	920mm	1PC

#### HARDWARE IDENTIFICATION

	HARDWARE NAME	FIGURE	QTY
1	BOLTS 3/16X40MM	<b>O</b> P	1PC
2	WASHER 60MM	0	1PC
2	ALLEN WRENCH M10		1PC


# ITEM:120341 ASSEMBLY INSTRUCTIONS





# ITEM:120341 ASSEMBLY INSTRUCTIONS





Note:Dimension tolerance±5%