ASSEMBLY INSTRUCTIONS - BM171956 EMERY BENCH

Important note:

- Place all wooden parts on a clean and smooth surface such as a rug or carpet to avoid scretching the parts.
 Kindly follow the assembly instructions step by step.
 Do not tighten all screws and bolts until the bench is fully assembled.

NO	COMPONENT	QTY
1	CUSHION SEAT	1
2	RIGHT LEG	2
3	LEFT LEG	2
4	STRETCHER	2

NO	HARDWARE		QTY
Α	BOLT	0	8
В	SPRING WASHER	0	8
С	FLAT WASHER	Ô	8
D	ALLEN KEY		1
E	SCREW	6	4

STEP 1





