



Assembly Instruction 761-3X Double Hamper Laundry Table

Parts List




A 1	Тор	1 pc
A2	Left Panel	1 pc
А3	Right Panel	1 pc
A4	Top and Bottom Crossbar	2 pcs



<u>Unit B</u>

B1	Side Panels	2 pcs
B2	Front and Back Crossbar	2 pcs
В3	Bottom Crossbar	1 pc



Unit C

C1	Inner Bag	2 pcs
C2	Round Wood	4 pcs


Hardware




Large Screw RF10181



Medium Screw RF10003




Allen wrench RF40003




L-Bracket RF50003




Small Screw RF10004



Step 1: Attach Top (A), Left Panel (A2), Right Panel (A3) and Crossbars (A4) together by using 8 Large screw (RF10181) as per diagram 1.



Attach 2 L-Bracket (RF50003) into the predrilled holes both side panels by using 6 Small screw (RF10004) as per diagram 2.



Step 4: Attach Side Panels (B1) into the Front and Back Crossbar (B2) by using 4 Large screw (RF10181) and Bottom Crossbar (B3) by using 2 Medium screw (RF10003) as per diagram 4.

