



## ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



*Fine Furniture for every stage of life*

**506592**  
Loveseat

REVISION 1: 05/12/2017  
REVISION 2: 05/08/2019  
REVISION 3: 05/16/2023  
REVISION 4: 10/13/2023  
REVISION 5: 10/21/2025

PAGE 1 OF 3

COASTERFURNITURE.COM

ITEM: 506592



## ASSEMBLY INSTRUCTIONS

### ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



### WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.




ASSEMBLY TIME

10 MINUTES


## PARTS IDENTIFICATION

AV      BASE



1PC

BV      BACK



1PC


CV      LEG



4PCS

## HARDWARE IDENTIFICATION

1      FLAT HEAD SCREW  
(Φ5 x 50mm - RBW)




12PCS

ITEM: 506592


## ASSEMBLY INSTRUCTIONS

**COASTER**  
FINE FURNITURE


### STEP 1





### STEP 2



### STEP 3




### STEP 4 COMPLETE



ITEM: 506592

**COASTER**  
FINE FURNITURE



**Note: Dimension tolerance  $\pm 5\%$**