

ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



602265 MOTION LOVESEAT WITH CONSOLE

REVISION 0: 05/17/2019 REVISION 1: 01/09/2020 PAGE 1 OF 4

COASTERFURNITURE.COM

ITEM: 602265

ASSEMBLY INSTRUCTIONS



ASSEMBLY INSTRUCTION

ASSEMBLY TIPS:

- 1.Remove hardware from box and sort by size.
- 2.Please check to see that all hardware and parts are present prior to start of assembly.
- 3.Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.

- MARNING!

 1.Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
 - 2. This product is for home use only and not intended for commercial establishment.





ASSEMBLY TIME PER UNIT: 15MINUTES

PARTS IDENTIFICATION

BASE 1PC

<u>B</u>	
	,

<u>1PC</u> LEFT BACK

<u>C</u>	
<u>C</u>	1_//

RIGHT BACK 1PC

<u>D</u>	
	-

<u>1PC</u> EAR LEFT

<u>E</u>	
\mathbf{F}	

RIGHT EAR 1PC

1PC



HARDWARE PACKAGE

1


2PCS **BOLT**

COASTERFURNITURE.COM

PAGE 2 OF 4

ITEM: 602265 ASSEMBLY INSTRUCTIONS






COASTERFURNITURE.COM

ITEM: 602265 ASSEMBLY INSTRUCTIONS







Note: Dimension tolerance ±5%