




Assembly Instructions



Caution : You must read this before you proceed

CLUB CHAIR






Part List








Label	Picture	Description	QTY
A		Seat	1
B		Chair Leg	4

C		Seat Cushion	1
D		Back Pillow	1

Hardware

Label	Picture	Description	QTY
①		Bolt (M6*15mm)	17
②		Washer	17
③		Allen Key	1

Assembly Preparation

Before Beginning Assembly:	   		
	 x17  x17 		



- Read instructions, cover to cover-



- Have 2 adults on hand for assembly-



- Do not assemble on flooring or carpet-




- Assemble on a clean non-marring surface (packing foam)-



- Save all packaging until finished-


Assembly Steps

Overview



This Chair has multiple parts and may require up to 30 minutes to assemble. To give you an overview of the Chair parts, the above picture is to help you put the various parts into perspective. Please read through the instructions below to familiarise yourself with the parts and steps before assembly.

Step 1



Open the carton and place all the parts onto a clean, non-marring surface.
Place Seat(A) facedown as shown in picture above.

Align Chair Leg(B) with mounting positions on the base of the Seat(A).


Attach Chair Leg(B) to Seat(A) using Bolts(1) and Washers(2) with Allen Key(3) as shown in the picture.

Note: The bottom of the Leg should be angled outwards.

Do not fully tighten the Bolts.


With the same process to assemble the remaining 3 Legs.

Step 2























Place the Chair on a **LEVEL SURFACE** to check for wobbles.
If it wobbles, carefully sit down on the Chair This action should allow all of the gaps to reach full alignment status.
When the Chair is level proceed to tighten all Bolts at all joints.
When tightening the Bolts, tighten sequentially.
DO NOT tighten any Bolt fully and then move on to the next one.

Step 3



Place the Seat Cushion(C) & Back Pillow(D) onto the Chair.
Your Chair is ready for use.
This Chair can only be used on a flat, level surface.

Care & Maintenance

-   ● Do not put hot items directly on furniture surface
 -   ● Do not clean furniture with harsh cleansers or polish.
 -   ● To obtain the longest lifespan of your outdoor products, minimizing exposure to direct sunlight is recommended.
 -   ● Children should not climb or jump on the furniture.
 -   ● Do not write on furniture without a padded barrier to protect the surface.
 -   ● To obtain the longest lifespan of your outdoor products, avoid extended and lengthy exposure to rain, snow, and direct sunshine. Whenever possible cover the product and /or place under patio or awnings.
 -   ● Not for commercial use. For residential use only .
 -   ● Stains may be removed with mild soap solution and damp cloth.
 -   ● Keep away from sources of ignition.
-
-   ● Dust and pick-up spills using a clean, non-colored, lint-free cloth.