


2400 / 2410 / 2420 - 150 CHEST


Assembly Instruction

<b>A. Components :</b>	<b>Qty</b>	<b>B. Hardware :</b>	<b>Qty</b>
1. Bun Feet :	4 Pcs	a. Allen Bolt :	4 Pcs
		b. Lock Washer :	4 Pcs
		c. Flat Washer :	4 Pcs
		d. Allen Key :	1 Pc

STEP - 1









STEP - 2



2400 / 2410 / 2420 - 150 CHEST

Assembly Instruction

A. Components :	Qty				B. Hardware :	Qty
1. Chest	1x			a. Screw ø8 x 2"	1 x	
		b		b. Screw ø8 x 5/8"	1 x	
				c. Restrain Strap	1 x	
		b	c	d. Metal Tabs	2 x	
				e. Plastic Wall Anchor	1 x	



**⚠ WARNING**

**Serious or fatal crushing injuries can occur from furniture tipover. To help prevent tip-over :**

- Install tipover restraint provided.
- Place heaviest items in the lowest drawers.
- Unless specifically designed to accommodate, do not set Tv's or other heavy objects on top of this product.
- Never allow children to climb or hang on drawers, doors or shelves.
- Never open more than one drawer at a time.

(OR)

- Do not defeat or remove the drawer interlock system.

**Use of tip over restraints may only reduce, but not eliminate the risk of tip-over.**

*This is a permanent label. Do not attempt to remove.*