
TOOLS REQUIRED

No Tools Required For Assembly





2 - People Recommended

ASSEMBLY RATING



EASY — DIFFICULT

The Assembly Rating is a 5-point system showing the level of effort needed to assemble a specific product.

VERSION # 19-11-16



Are you missing anything?	Check out our Quick Tips!
Double-check all parts, hardware and accessories listed on Page 6 are accounted for.	We recommend reviewing the pre-assembly handouts. Even experts need a refresher now and then!
Should we send any replacements? Are there any irregularities or flaws in the parts? We can send replacements!	Prep Time! Please review the assembly instructions and all diagrams prior to assembling. Arrange parts as recommended on Page 7 and group identical
	hardware together to make assembling easier.

PRE ASSEMBLY INTRODUCTION

We understand building ready-to-assemble furniture can be a challenging experience for some. To help avoid confusion, we have provided some helpful tips that may speed up the process.





Teamwork

ALWAYS have at least two people to help with transporting and assembling the product to avoid potential injury and/or damage.





Suitable Location

Assembling near the area of the intended location is highly recommended.





Sufficient Space

Make sure you have enough space to move around during the assembly.





Avoid Scratches

Use cardboard, blankets or a carpeted area while assembling furniture to prevent scratches.





Flat Surface

Make sure the furniture rests on a flat and level surface with each leg evenly touching the floor.

ASSEMBLY AND CARE ADVICE




FAILURE TO FOLLOW THE GUIDELINES BELOW MAY RESULT IN INJURY AND/OR PROPERTY DAMAGE.



Position each part correctly and insert screws or bolts into their respective holes.




Use the appropriate hand tools or power tools for assembly. Select steps, such as tightening screws and/or bolts, may require hand tools to avoid causing damage during assembly.



Turn clockwise to tighten and only tighten when step is completed or when instructed to do so.



Save the instructions and store any supplied tools for later maintenance.




After two weeks, check and tighten any loose hardware and repeat again every six months thereafter.

IT IS THE USER'S RESPONSIBILITY TO MAINTAIN THE FURNITURE. THE HARDWARE MAY LOOSEN OVER TIME AND MAY CAUSE THE FURNITURE TO BE WOBBLY AND UNABLE TO SUPPORT ITS INTENDED WEIGHT CAPACITY. THIS MAY LEAD TO COLLAPSE AND MAY CAUSE SERIOUS INJURY.



- · Please keep instructions for future reference.
- Check the quantity and irregularity of parts and hardware before you start.



PARTS





Left Seat Frame








Right Seat Cushion





Chair Back





#2)1pc



Left Seat Cushion





Right Back Cushion





#3 1pc



Left Back Cushion





Chair Frame



Pillow






Right Seat Frame






Chair Seat



Leg


Plastic Washer

Exploded View



Remove parts from the bottom compartment of the left seat frame (#1).

1




2

Part #1 x1pc Part #12 x5pcs


Part #13 x5pcs

Align and attach legs (#12) with washers (#13) to left seat frame (#1).




3

Part #2 x1pc




4

Part #3 x1pc
Part #1 x1pc



5

Remove parts from the bottom compartment of the right seat frame (#4).




6


Part #4 x1pc
Part #12 x5pcs

Part #13 x5pcs

Attach legs (#12) with washers (#13) to right seat frame (#4).




7
Part #5 x1pc




8

Part #6 x1pc
Part #1 x1pc



9


Remove parts from bottom compartment of chair frame (#7).



x 2


10

Part #7 x1pc Part #12 x4pcs Part #13 x4pcs Attach legs (#12) with washers (#13) to the chair frame (#7).




11

Part **#8** x1pc




12

Part #1 x1pc



13

Remove parts from the bottom compartment of the ottoman (#10).




14

Part #10 x1pc


Part #12 x4pcs
Part #13 x4pcs

Attach legs (#12) with washers (#13) to the ottoman (#10).



15

Align and hook the metal brackets of the sectional pieces together.



ASSEMBLY COMPLETED



Please ensure the furniture rests on an even and flat surface. If the product wobbles or feels loose, double-check all bolts and/or screws are properly tightened and secured.

✓ Keep this handy!

Please retain this instruction manual and any order-related information for future reference.

✓ Lift, don't drag!

To avoid damage to product please always LIFT the product when transporting of adjusting the placement.