


ASSEMBLY INSTRUCTIONS




TOOLS REQUIRED



Wrench

(Included)



**2 - Persons
Recommended**

ASSEMBLY RATING



EASY —————> DIFFICULT

The Assembly Rating is a 5-point system showing the level of effort needed to assemble a specific product.



CHECK BEFORE STARTING



Are you missing anything?

Double-check all parts, hardware and accessories listed on Page 6 are accounted for.



Should we send any replacements?

Are there any irregularities or flaws in the parts? We can send replacements!



Check out our Quick Tips!

We recommend reviewing the pre-assembly handouts. Even experts need a refresher now and then!



Prep Time!

Please review the assembly instructions and all diagrams prior to assembling. Set up your workspace by laying the parts and hardware out separately, then begin!



PRE ASSEMBLY INTRODUCTION

We understand building ready-to-assemble furniture can be a challenging experience for some. To help avoid confusion, we have provided some helpful tips that may speed up the process.



Teamwork

ALWAYS have at least two people to help with transporting and assembling the product to avoid potential injury and/or damage.



Suitable Location

Assembling near the area of the intended location is highly recommended.





Sufficient Space

Make sure you have enough space to move around during the assembly.



Avoid Scratches

Use cardboard, blankets or a carpeted area while assembling furniture to prevent scratches.



Flat Surface

Make sure the furniture rests on a flat and level surface with each leg evenly touching the floor.


ASSEMBLY AND CARE ADVICE



FAILURE TO FOLLOW THE GUIDELINES BELOW MAY RESULT IN INJURY AND/OR PROPERTY DAMAGE.



Position each part correctly and insert screws or bolts into their respective holes.




Turn clockwise to tighten and only tighten when step is completed or when instructed to do so.



Use the appropriate hand tools or power tools for assembly. Select steps, such as tightening screws and/or bolts, may require hand tools to avoid causing damage during assembly.



Save the instructions and store any supplied tools for later maintenance.




After two weeks, check and tighten any loose hardware and repeat again every six months thereafter.

IT IS THE USER'S RESPONSIBILITY TO MAINTAIN THE FURNITURE. THE HARDWARE MAY LOOSEN OVER TIME AND MAY CAUSE THE FURNITURE TO BE WOBBLY AND UNABLE TO SUPPORT ITS INTENDED WEIGHT CAPACITY. THIS MAY LEAD TO COLLAPSE AND MAY CAUSE SERIOUS INJURY.

GAME TABLE



- Please keep instructions for future reference.
- Check the quantity and irregularity of parts and hardware before you start.



PARTS

#1 1pc






Table Top

#2 1pc




Apron

#3 1pc



Wood Panel

#4 1pc



Base

#5 4pcs



Leg


HARDWARE

#A 4pcs



Bolt \varnothing 5/16" x 1-3/4"

#B 16pcs




Flat Washer \varnothing 5/16"

#C 12pcs




Hex Nut \varnothing 5/16"

#D 1pc



Wrench

#E 16pcs



Sponge Mat

#F 4pcs



Lock Washer \varnothing 5/16"

ASSEMBLY INSTRUCTIONS

1

1. Insert the threaded ends of the leg (#5) into the holes along the sides of the base (#4).


Part #4 x1pc

Part #5 x4pcs

Hardware #B x8pcs

Hardware #C x8pcs

2. Apply a washer (#B) then a hex nut (#C) onto the threaded end from within. Then secure using the wrench (#D).



3. Repeat the process with the remaining legs (#5).

2


2. Place the wood panel (#3) onto the threaded ends along the top of the base (#4).

Part #3 x1pc

Hardware #B x4pcs

Hardware #C x4pcs

1. Turn the base (#4) upright.




3. Apply a washer (#B) then a hex nut (#C) onto the threaded ends, then secure using the wrench (#D).

ASSEMBLY INSTRUCTIONS

3

- Part #2 x1pc
- Hardware #A x4pcs
- Hardware #B x4pcs
- Hardware #F x4pcs

3. Insert the bolt assemblies into the wood panel (#3) and secure using the wrench.



1. Place the apron (#2) face down onto a protected surface. Then align the wood panel (#3) to the holes located in the center.


2. Prepare 4 bolt assemblies by first inserting a lock washer (#F) onto the bolt (#A) then a washer (#B) onto that same bolt (#A).

4

- Part #1 x1pc
- Hardware #E x16pcs

1. Turn the table upright.

2. Carefully place the table top (#1) onto the apron (#2).



ASSEMBLY COMPLETED



Please ensure the furniture rests on an even and flat surface. If the product wobbles or feels loose, double-check all bolts and/or screws are properly tightened and secured.



Keep this handy!

Please retain this instruction manual and any order-related information for future reference.