

TOOLS REQUIRED



Allen Wrench

(Included)



Philips Screwdriver

(Not Included)



2 - People Recommended

ASSEMBLY RATING



EASY → DIFFICULT

The Assembly Rating is a 5-point system showing the level of effort needed to assemble a specific product.



Are you missing anything?	Check out our Quick Tips!
Double-check all parts, hardware and accessories listed on Page 6 are accounted for.	We recommend reviewing the pre-assembly handouts. Even experts need a refresher now and then!
Should we send any replacements? Are there any irregularities or flaws in the parts? We can send replacements!	Prep Time! Please review the assembly instructions and all diagrams prior to assembling. Arrange parts as recommended on Page 7 and group identical hardware together to make assembling easier.

PRE ASSEMBLY INTRODUCTION

We understand building ready-to-assemble furniture can be a challenging experience for some. To help avoid confusion, we have provided some helpful tips that may speed up the process.





Teamwork

ALWAYS have at least two people to help with transporting and assembling the product to avoid potential injury and/or damage.





Suitable Location

Assembling near the area of the intended location is highly recommended.





Sufficient Space

Make sure you have enough space to move around during the assembly.





Avoid Scratches

Use cardboard, blankets or a carpeted area while assembling furniture to prevent scratches.





Flat Surface

Make sure the furniture rests on a flat and level surface with each leg evenly touching the floor.

ASSEMBLY AND CARE ADVICE




FAILURE TO FOLLOW THE GUIDELINES BELOW MAY RESULT IN INJURY AND/OR PROPERTY DAMAGE.



Position each part correctly and insert screws or bolts into their respective holes.



Use the appropriate hand tools or power tools for assembly. Select steps, such as tightening screws and/or bolts, may require hand tools to avoid causing damage during assembly.



Turn clockwise to tighten and only tighten when step is completed or when instructed to do so.



Save the instructions and store any supplied tools for later maintenance.




After two weeks, check and tighten any loose hardware and repeat again every six months thereafter.

IT IS THE USER'S RESPONSIBILITY TO MAINTAIN THE FURNITURE. THE HARDWARE MAY LOOSEN OVER TIME AND MAY CAUSE THE FURNITURE TO BE WOBBLY AND UNABLE TO SUPPORT ITS INTENDED WEIGHT CAPACITY. THIS MAY LEAD TO COLLAPSE AND MAY CAUSE SERIOUS INJURY.

COFFEE TABLE



- · Please keep instructions for future reference.
- Check the quantity and irregularity of parts and hardware before you start.



PARTS



1pc



Table Top



1pc



Glass Top





Leg B

HARDWARE





Bolt 5/16" x 7/8"





Flat Bolt 5/16" x 7/8"



#© 12pcs



Lock Washer 5/16"



#D 12pcs



Flat Washer 5/16"





Allen Wrench M5



1pc



4-Way Bracket




Bracket

Align the two brackets (#G) with the pre-drilled holes of the leg A (#2). Insert 4 bolts (#B) into the brackets (#G) using the Allen wrench (#E) to lock them with the leg A (#2).

1




Turn right (clockwise) to tighten



2

Part #3 x1pc
Hardware #B x4pcs
Hardware #G x2pcs

Align the two brackets (#G) with the pre-drilled holes of the leg B (#3). Insert 4 bolts (#B) into the brackets (#G) using the Allen wrench (#E) to lock them in with the leg B (#3).



Part #1) x1pc

Part (#4) x1pc

Hardware (#A) x12pcs

Hardware (#C) x12pcs

Hardware (#D) x12pcs


Hardware (#F) x1pc

I. Carefully place the table top (#1) facing down on a protected surface.

II. Align the brackets (#G) assembled on the leg A (#2) AND the leg B (#3) with the pre-drilled holes on the bottom of the table top (#1).

- III. Prepare 8 bolt assemblies by inserting FIRST the lock washer (#C) onto the bolt (#A) and then the flat washer (#D) onto the SAME bolt (#A), in that order.
- IV. Insert the bolt assemblies through the pre-drilled holes on the brackets (#G) and secure those bolts using the Allen wrench (#E) to lock them with the table top (#1).
- V. Align the 4-way bracket (#F) onto the center of the leg A (#2) and the leg B (#3).
- VI. Prepare 4 bolt assemblies by inserting FIRST the lock washer (#C) onto the bolt (#A) and then the flat washer (#D) onto the SAME bolt (#A), in that order.
- VII. Insert the bolt assemblies through the pre-drilled holes on the 4-way bracket (#F) and secure those bolts using the Allen wrench (#E) to lock them with the leg A (#2) AND the leg B (#3).
- VIII. Carefully turn the table upright. Place the glass top (#4) onto the table top (#1). Make sure the table is rested on a flat surface and it does not feel loose or wobbly. If it does, double check that the bolts/screws are secured and properly tighten.


ASSEMBLY



STOOL



- Please keep instructions for future reference.
- Check the quantity and irregularity of parts and hardware before you start.



X 4

Note: The above parts and hardware are shown for a complet assembly of ONE chair. However, the actual parts and hardware (with an exception of the Allen wrench) in the box will be four times the quantities listed to include the assembly of the second, third and fourth chairs.

PARTS



1pc x 4



Seat Cushion



1pc x 4



Center Leg



1pc x 4



Seat Frame



2pcs x 4



Side Leg



1pc x 4



Base

HARDWARE



6pcs x 4



Bolt 5/16" x 1-3/4"



6pcs x 4



Lock Washer 5/16"



6pcs x 4



Flat Washer 5/16"





Allen Wrench M5



4pcs x 4




Screw

Part (2) x1pc
Part (4) x1pc
Part (45) x2pcs
Hardware (4) x3pcs
Hardware (4) x3pcs
Hardware (4) x3pcs

Turn right (clockwise) to tighten


- I. Insert the center leg (#4) and the two side legs (#5) into the seat frame (#2).
- II. Prepare 3 bolt assemblies by inserting FIRST the lock washer (#B) onto the bolt (#A) and then the flat washer (#C) onto the SAME bolt (#A), in that order.
- III. Insert the bolt assemblies through the pre-drilled holes on the seat frame (#2) and secure those bolts using the Allen wrench (#D) to lock them in with the center leg (#4) and the two side legs (#5).



2


Part #1 x1pc
Hardware#E x4pcs

Align the seat cushion (#1) onto the top of the seat frame (#2). Tighten 4 screws (#E) through the bottom of the seat frame (#2) using the Phillips screwdriver to secure them with the seat cushion (#1).




Turn right (clockwise) to tighten

- Part #3 x1pc
 Hardware #A x3pcs
 Hardware #B x3pcs
 Hardware #C x3pcs
 - I. Insert the assembled center leg (#4) and the side legs (#5) into the base (#3).
 - II. Prepare 3 bolt assemblies by inserting FIRST the lock washer (#B) onto the bolt (#A) and then the flat washer (#C) onto the SAME bolt (#A), in that order.
 - III. Insert the bolt assemblies through the pre-drilled holes on the base (#3) and secure those bolts using the Allen wrench (#D) to lock them with the assembled center leg (#4) and the side legs (#5).
 - IV. Make sure the chair is rested on a flat surface and it does not feel loose or wobbly. If it does, double check that the bolts/screws are secured and properly tighten.



Turn right (clockwise) to tighten

4



ASSEMBLY COMPLETED



Please ensure the furniture rests on an even and flat surface. If the product wobbles or feels loose, double-check all bolts and/or screws are properly tightened and secured.

✓ Keep this handy!

Please retain this instruction manual and any order-related information for future reference.

Lift, don't drag!

To avoid damage to product please always LIFT the product when transporting of adjusting the placement.

ASSEMBLE EVERYTHING EXACTLY THE SAME FOR THE OTHER THREE CHAIRS.