


Assembly Instructions



ASSEMBLY RATING

The Assembly Rating is a 5-point system that shows the degree of effort needed in assembling a specific product (with 1 being easy and 5 being difficult). For some products, two persons are recommended.


EASY



DIFFICULT

Tools Required For Assembly:

Allen Wrench



(Included)

Phillips Screwdriver




(Not Included)


ASSEMBLY & CARE ADVICE

FOR YOUR FURNITURE TO LAST, CORRECT ASSEMBLY AND PROPER MAINTENANCE ARE NECESSARY. PLEASE FOLLOW THE INFORMATION PROVIDED BELOW TO FULLY ENJOY YOUR FURNITURE.


BASIC ASSEMBLY TECHNIQUES




When lock or spring washer is used in an assembly, please make sure the lock or spring washer is placed between the larger flat washer and the head of the screw or bolt.




Position each part correctly and insert screws or bolts into their respective holes by hand tighten or using the proper hand tool. Only tighten when step is completed or when instructed to do so.




Use cardboard or carpet area when assembling furniture to prevent scratches. Make sure the furniture rests on a flat and level surface with each leg evenly touching the floor.



Some furniture comes with height adjustment knobs underneath each leg. To lower or to raise each leg, you need to turn clockwise or counterclockwise, respectively.



Make sure all parts are properly aligned, then use the appropriate hand tool to completely tighten the bolts or screws. Do not use power tools and do not overtighten.




Save the instructions and store the Allen wrench or any supplied tool for later maintenance. After two weeks, check and tighten any loose hardware and repeat again every six months thereafter.

IT IS THE USER'S RESPONSIBILITY TO MAINTAIN THE FURNITURE. THE HARDWARE MAY LOOSEN OVER TIME AND MAY CAUSE THE FURNITURE TO BE WOBBLY AND UNABLE TO SUPPORT ITS INTENDED WEIGHT CAPACITY. THIS MAY LEAD TO COLLAPSE AND MAY CAUSE SERIOUS INJURY.




FAILURE TO FOLLOW THE GUIDELINES ABOVE MAY RESULT IN INJURY AND/OR PROPERTY DAMAGE.



Before you begin, please read Page 2 of "Assembly and Care Advice".

And remember, do not tighten until each step is completed or instructed.


Parts List




#1 x 1pc
Chair Back




#2 x 1pc
Seat Cushion




#3 x 1pc
Left Leg




#4 x 1pc
Right Leg




#5 x 1pc
Left Arm




#6 x 1pc
Right Arm



#7 x 1pc
Right Crossbars




#8 x 1pc
Left Crossbars



#9 x 1pc
Centre Crossbars


Hardware List




#A x 14pcs
Flat Washer Ø1/4"




#B x 16pcs
Lock Washer Ø1/4"




#C x 4pcs
Bolt Ø1/4" x3"




#D x 4pcs
Bolt Ø1/4" x2-1/2"




#E x 8pcs
Bolt Ø1/4" x2"



#F x 1pc
Allen Wrench M4



#G x 4pcs
Screws #8x1-1/2"




#H x 2pcs
Screws #8x1"



1) Prepare 2 bolts assembly by inserting lock washer (#B), then flat washer (#A) onto bolts (#E). Align seat cushion (#2) to the holes of the chair back (#1). Secure middle holes with bolts (#E).

#A x 6pcs
#B x 6pcs
#C x 4pcs
#E x 2pcs




2) Prepare 4 bolts assembly by inserting lock washer (#B), then flat washer (#A) onto bolts (#C). Secure corner holes of the seat cushion (#2) with bolts (#C).




2) Align crossbars (#7,8,9) in-between the legs of the chair as shown in the picture. Secure middle crossbar (#9) to side crossbars (#7,8) with screws (#H). Secure crossbars (#7,8) to legs with screws (#G).

#A x 4pcs
#B x 4pcs
#D x 4pcs
#G x 4pcs
#H x 2pcs




1) Prepare 4 bolts assembly by inserting lock washer (#B), then flat washer (#A) onto bolts (#D). Align left and right legs (#3,4) to the holes of the seat cushion (#2) as shown in the picture. Secure with bolts (#D), but do not tighten.



1) Prepare 4 bolts assembly by inserting lock washer (#B), then flat washer (#A) onto bolts (#E). Align arms (#5,6) to the holes of the chair. Secure arms (#5,6) to seat cushion with bolts (#E).

#A x 4pcs
#B x 6pcs
#E x 6pcs



2) Prepare 2 bolts assembly by inserting lock washer (#B) onto bolts (#E). Secure arms (#5,6) to the chair back with bolts (#E).



Assembly Completed

If wobbly, please ensure to level the chair with the floor, and adjust the bolts gradually until the chair does not wobble anymore.

