
Assembly Instructions



ASSEMBLY RATING

The Assembly Rating is a 5-point system that shows the degree of effort needed in assembling a specific product (with 1 being easy and 5 being difficult). For some products, two persons are recommended.



Tools Required For Assembly:

Allen Wrench

(Included)

Phillips Screwdriver






2 PERSONS RECOMMENDED

Rev: 19-07-17


ASSEMBLY & CARE ADVICE

FOR YOUR FURNITURE TO LAST, CORRECT ASSEMBLY AND PROPER MAINTENANCE ARE NECESSARY. PLEASE FOLLOW THE INFORMATION PROVIDED BELOW TO FULLY ENJOY YOUR FURNITURE.


BASIC ASSEMBLY TECHNIQUES




When lock or spring washer is used in an assembly, please make sure the lock or spring washer is placed between the larger flat washer and the head of the screw or bolt.




Position each part correctly and insert screws or bolts into their respective holes by hand tighten or using the proper hand tool. Only tighten when step is completed or when instructed to do so.




Use cardboard or carpet area when assembling furniture to prevent scratches .Make sure the furniture rests on a flat and level surface with each leg evenly touching the floor. No dragging of products/parts.



Some furniture comes with height adjusetment knobs underneath each leg. To lower or to raise each leg, you need to turn clockwise or counterclockwise, respectively.




Make sure all parts are properly aligned, then use the appropriate hand tool to completely tighten the bolts or screws. Do not use power tools and do not overtighten.




Save the instructions and store the Allen wrench or any supplied tool for later maintenance. After two weeks, check and tighten any loose hardware and repeat again every six months thereafter.

IT IS THE USER'S RESPONSIBILITY TO MAINTAIN THE FURNITURE. THE HARDWARE MAY LOOSEN OVER TIME AND MAY CAUSE THE FURNITURE TO BE WOBBLY AND UNABLE TO SUPPORT ITS INTENDED WEIGHT CAPACITY. THIS MAY LEAD TO COLLAPSE AND MAY CAUSE SERIOUS INJURY.









Before you begin, please read Page 2 of "Assembly and Care Advice".


And remember, do not tighten until each step is completed or instructed.







Before you begin, please read Page 2 of "Assembly and Care Advice".


And remember, do not tighten until each step is completed or instructed.








Page 7 of 10



Page 8 of 10



Page 9 of 10

Safety Warnings for Bunk beds

- 1. Read and follow the information on the WARNINGS shown on the end structure of the upper bunk and on the carton.
- 2. Do not remove warning label from the bed.
- 3. Keep these instructions for future reference.
- 4. IMPORTANT: **Must use Bunkie mattress or Bunkie board**. The proper sizes for the **UPPER/LOWER TWIN SIZE** Bunkie mattress or Bunkie board should be 74" long and $37\frac{1}{2}$ " $38\frac{1}{2}$ " wide with no more than 6" thickness and for the **UPPER/LOWER FULL- SIZE should be 74" long and 53"-54" wide with no more than 8" thickness.**
- 5. Surface of mattress must be at least 5 inches (127mm) **BELOW** the upper edge of guardrails.
- 6. The MAXIMUM weight capacity for the upper bunk is not to exceed 175 lbs.
- 7. Do not allow children under 6 years of age to use the upper bunk.
- 8. Periodically check and ensure that the guardrails, ladder, handle and other components are in their proper position, free from damage, and that all connectors are tightened and secured.
- 9. DO NOT allow horseplay, rough playing or jumping on the beds and do not allow playing or hiding under the beds.
- 10. Always use the ladder for enteringor leaving the upper bunk.
- 11. Do not use substitute parts. Contact the manufacturer or dealer for replacement parts.
- 12. Use of a nightlight may provide added safety precaution for a person using the upper bunk.
- 13. Always use the guardrails on both sides of the upper bunk.
- 14. If the bunk bed will be placed next to a wall, the guardrail that runs the full length of the bed should be placed against the wall to prevent antrapment between the bed and the wall.
- 15. The use of water or sleep flotation mattresses is prohibited.
- 16. No more than one person is allowed on the upper bunk at all times.



WARNING: STRANGULATION HAZARD

Never attach or hang objects to any part of the bunk bed that are not designed for use with the bed. Objects such as hanger, hook, belt, bag, rope, string, etc. Should not be used on or around the bunk bed.