
# **Assembly Instructions**



## **ASSEMBLY RATING**

The Assembly Rating is a 5-point system that shows the degree of effort needed in assembling a specific product (with 1 being easy and 5 being difficult). For some products, two persons are recommended.

EASY OOOO DIFFICULT

## **Tools Required for Assembly:**

Allen Wrench

(Included)

Phillips Screwdriver




2 PERSONS RECOMMENDED

# ASSEMBLY & CARE ADVICE

FOR YOUR FURNITURE TO LAST, CORRECT ASSEMBLY AND PROPER MAINTENANCE ARE NECESSARY.

PLEASE FOLLOW THE INFORMATION PROVIDED BELOW TO FULLY ENJOY YOUR FURNITURE.


#### **BASIC ASSEMBLY TECHNIQUES**




When lock or spring washer is used in an assembly, please make sure the lock or spring washer is placed between the larger flat washer and the head of the screw or bolt.




Position each part correctly and insert screws or bolts into their respective holes by hand tighten or using the proper hand tool. Only tighten when step is completed or when instructed to do so.




Use cardboard or carpet area when assembling furniture to prevent scratches. Make sure the furniture rests on a flat and level surface with each leg evenly touching the floor.



Some furniture comes with height adjustment knobs underneath each leg. To lower or to raise each leg, you need to turn clockwise or counterclockwise, respectively.



Make sure all parts are properly aligned, then use the appropriate hand tool to completely tighten the bolts or screws. Do not use power tools and do not overtighten.




Save the instructions and store the Allen wrench or any supplied tool for later maintenance. After two weeks, check and tighten any loose hardware and repeat again every six months thereafter.

IT IS THE USER'S RESPONSIBILITY TO MAINTAIN THE FURNITURE. THE HARDWARE MAY LOOSEN OVER TIME AND MAY CAUSE THE FURNITURE TO BE WOBBLY AND UNABLE TO SUPPORT ITS INTENDED WEIGHT CAPACITY. THIS MAY LEAD TO COLLAPSE AND MAY CAUSE SERIOUS INJURY.



FAILURE TO FOLLOW THE GUIDELINES ABOVE MAY RESULT IN INJURY AND/OR PROPERTY DAMAGE.



Before you begin, please read Page 2 of "Assembly and Care Advice".

And remember, do not tighten until each step is completed or instructed.


MD

# **Parts List**


DRAWING	DESCRIPTION	QTY
<11/		
الماليل الماليل	BACK PANEL	1PC
	ARC PANEL	2PCS
	SIDE PANEL	2PCS
	LEFT FRAME FOR KEYBOARD	1PC
	RIGHT FRAME FOR KEYBOARD	1PC
=	TABLE TOP GLASS	1PC
	TOP CROSS BAR	1PC
	WOOD SHELF	1PC
	LEFT SLIDE	1PC
	RIGHT SLIDE	1PC
		SIDE PANEL  LEFT FRAME FOR KEYBOARD  RIGHT FRAME FOR KEYBOARD  TABLE TOP GLASS  TOP CROSS BAR  WOOD SHELF  LEFT SLIDE

## **Hardware List**


#	DRAWING	DESCRIPTION	QTY
#A	0)	BOLT 1/4"x 5/8"	6PCS
#B	0	BOLT 1/4"x 1 <sup>1</sup> / <sub>2</sub> "	4PCS
#C	©mmm	BOLT 1/4"x 1 <sup>1</sup> / <sub>2</sub> "	4PCS
#D	(a)	BOLT 1/4"x 3 <sup>1</sup> / <sub>4</sub> "	2PCS
#E	S	BOLT <sup>3</sup> / <sub>16</sub> "x <sup>1</sup> / <sub>2</sub> "	4PCS
#F	<b>()</b>	BOLT M4x 13mm	4PCS
#G	0	WASHER Ø16mm	8PCS
# H		ø20mm	6PCS
# I	Ф	LEVELER 1/4"	4PCS
#J		ALLEN WRENCH 4x4x60mm	1PC




Due to the size and/or weight of this product, it is highly recommended that the assembly should be done near the area of its intended location. Make sure you have enough space to move around during the assembly. ALWAYS have at least two people to help with transporting and assembling the product to avoid any potential injury and/or damage.




Page 5 of 8



Page 6 of 8



Page 7 of 8



Page 8 of 8