
# **Assembly Instructions**


## Sofa



Part List				
Label	Picture	Description	QTY	
А		Left Armrest	1	
В		Right Armrest	1	
С		Backrest	1	
D		Sofa Seat	1	
E		Seat Cushion	3	
F	7.4	Back Cushion	3	

<u>Hardware</u>			
Label	Picture	Description	QTY
1	<b>a</b>	Bolt (M6*40mm)	15
2	0	Washer Rings	15
3		Allen Key	1

### Assembly Preparation





- Read instructions, cover to cover-
- **P**2X
- Have 2 adults on hand for assembly-




- Do not assemble on flooring or carpet-
- · Assemble on a clean non-marring surface (packing foam)-




Save all packaging until finished-

### **Assembly Steps**



This Sofa has multiple parts and may require up to some 30 minutes to assemble. To give you an overview of the Love Seat parts, the above picture is to help you put the various parts into perspective. Please read through the instructions here below to familiarise yourself with the parts and steps before assembly.



Open the carton and place all the parts onto a clean and soft surface.


Unpack all packages of hardware.

Place the Backrest (C) to Right Armrest (B), make the metal rod on the Sofa Back (C) insert into the mounting position.

Attachthe Backrest (C) and Right Armrest (B) together using Bolts (1) and Washers (2) with Allen Key (3) as shown in Picture.


#### DO NOT FULLY TIGHTEN THE BOLTS.

ATTENTION: There may be some PE wicker that may have covered the bolt points. To ease assembly, guide and slide the PE wicker away from the mounting positions. DO NOT CUT AWAY any PE WICKER as this would cause the wicker to unravel!




Attach Sofa Seat (D) between the Right Armrest (B) and Sofa Back (C) using Bolts (①) and Washers (②) with Allen Key (③) as shown in Picture.

#### DO NOT FULLY TIGHTEN THE BOLTS.



Attach Left Armrest(A) with the Sofa Seat (D) and Sofa Back (C) using Bolts (①) and Washers (②) with Allen Key (③) as shown in Picture.

#### DO NOT FULLY TIGHTEN THE BOLTS.



Turn the Sofa right side up.

Place the Sofa on a LEVEL SURFACE to check for wobbles.

If it wobbles, lift the Sofa some 30cm to 50cm high from the ground.

Keep your feet and toes well away from the drop zone.

Drop the Sofa freely and vertically with all four legs, hitting the ground, all at the same time.

This drop test will help to ensure that all the bolts and gaps reach full alignment status.

Test again for eveness on a LEVEL SURFACE.

If no wobbles are found, slowly and steadily, place the Loveseat face down.

Then, proceed to tighten all bolts in a sequential manner.

When tightening the Bolts, tighten sequentially.


DO NOT tighten any Bolt fully and then move on to the next one.

This may cause the frame to warp.

If there is still wobbles, loosen the bolts and execute this same process.

If the Loveseat is not stable it could lead to damage to the product.

### Step 5



Put the Seat Cushion(E) and Back Cushion(F) on the Sofa. Your Sofa is ready for use.

This Sofa can only be used on the flat and level surface.

### **Care & Maintenance**



• Prolonged exposure to rain may cause rusting which can stain floors.



Do not put hot items directly on furniture surface.



Do not clean furniture with harsh cleansers or polish.



To obtain the longest lifespan of your outdoor products, minimizing exposure to direct sunlight is recommended.



• Children should not climb or jump on the furniture.



• Do not write on furniture without a padded barrier to protect the surface.



To obtain the longest lifespan of your outdoor products, avoid extended and lengthy exposure to rain, snow, and direct sunshine. Whenever possible cover the product and /or place under patio or awnings.



Not for commercial use. For residential use only.



• Stains may be removed with mild soap solution and damp cloth.



• Keep away from sources of ignition.



Dust and pick-up spills using a clean, non-colored, lint-free cloth.