ASSEMBLY INSTRUCTIONS

Read this instruction carefully. See hardware and furniture part list for guidance. Be sure all parts are complete, before you assemble. Place all wooden furniture parts on a clean and flat soft surface to prevent from being scratched. Follow the figure to start assembling.

CAUTIONS: 1. Do not FULLY - TIGHTEN the nut or nut bolt until all nut or bolt is ready assembed.

2. Do not OVER - TIGHTEN the nut or bolt to avoid causing damages to the thread.

3. Keep all hardware parts out of reach of children.

NOTE: THE LIST AND QUANTITY SHOWN ARE FOR 1 UNIT ASSEMBLY.

Tool needed: Screwdriver & Hammer (not provider).

PART LIST			
ITEM	DESCRIPTION	QTY	
Α	HEADBOARD (LEFT)	1 PC	
В	HEADBOARD (RIGHT)	1 PC	
С	FOOTBOARD	1 PC	
D	SIDE RAIL (L&R)	2 PCS	
E	CENTER RAIL	2 PCS	
F	CENTER SUPPORT LEG	6 PCS	
G	LEG	4 PCS	
Н	BED SLAT	1 SET	
I	SIDE RAIL SUPPORT	2 PCS	

HARDWARE LIST				
ITEM	DESCRIPTION		QTY	
1	JCBC BOLT M6 x 20mm	cccccc	4 PCS	
2	JCBC BOLT M6 x 30mm	(((((((()	2 PCS	
3	JCBC BOLT M6 x 45mm	((((((((((((((((((((((((((((((((((((((8 PCS	
4	JCBB BOLT M8 x 40mm	«««««« ©	4 PCS	
5	JCBB BOLT M8 x 50mm		16 PCS	
6	M6 SPRING WASHER	0	6 PCS	
7	M6 FLAT WASHER	0	6 PCS	
8	M8 SPRING WASHER	0	20 PCS	
9	M8 FLAT WASHER	0	20 PCS	
10	WOOD SCREW M4 x 25mm		12 PCS	
11	WOOD SCREW M4 x 38mm		12 PCS	
12	WOOD DOWEL M10 x 30mm		10 PCS	
13	M4 ALLEN KEY (BALL SHAPE)		1 PC	
14	M5 ALLEN KEY (BALL SHAPE)		1 PC	
15	VMB 3062 L Bracket	印	2 PCS	
16	VMB 3069	<u> </u>	1 PC	







